

---

# OWNER'S MANUAL

---

## NAVY TROLLEY HOIST

MODEL NTH

1 Ton through 5 Ton Capacity

Code, Lot and Serial Number

### **⚠ WARNING**

This equipment should not be installed, operated or maintained by any person who has not read and understood all the contents of this manual. Failure to read and comply with the contents of this manual can result in serious bodily injury or death, and/or property damage.

**HARRINGTON**<sup>®</sup>  
**HOISTS AND CRANES**



# Table of Contents

| <b>Section</b>                                | <b>Page Number</b> |
|---|--------------------|
| 1.0 Important Information and Warnings .....  | 4                  |
| 1.1 Terms and Summary                         |                    |
| 1.2 Warning Tags and Labels                   |                    |
| 2.0 Technical Information.....                | 8                  |
| 2.1 Specifications                            |                    |
| 2.2 Dimensions                                |                    |
| 2.3 Optional Equipment                        |                    |
| 3.0 Preoperational Procedures .....           | 12                 |
| 3.1 Chain                                     |                    |
| 3.2 Attachment Points                         |                    |
| 3.3 Mounting the Hoist                        |                    |
| 3.4 Preoperational Checks and Trial Operation |                    |
| 4.0 Operation .....                           | 17                 |
| 4.1 Introduction                              |                    |
| 4.2 Shall's and Shall Not's for Operation     |                    |
| 4.3 Safety Consideration                      |                    |
| 4.4 Operation                                 |                    |
| 5.0 Inspection .....                          | 20                 |
| 5.1 General                                   |                    |
| 5.2 Inspection Classification                 |                    |
| 5.3 Frequent Inspection                       |                    |
| 5.4 Periodic Inspection                       |                    |
| 5.5 Occasionally Used Hoists                  |                    |
| 5.6 Inspection Records                        |                    |

**Section****Page Number**

---

|     |                                      |    |
|-----|--------------------------------------|----|
| 5.7 | Inspection Methods and Criteria      |    |
| 6.0 | Maintenance & Handling .....         | 30 |
| 6.1 | Lubrication                          |    |
| 6.2 | Disassembly, Assembly and Adjustment |    |
| 6.3 | Hoist Disassembly                    |    |
| 6.4 | Hoist Assembly                       |    |
| 6.5 | Storage                              |    |
| 6.6 | Outdoor Installation                 |    |
| 7.0 | Troubleshooting .....                | 38 |
| 8.0 | Warranty .....                       | 41 |
| 9.0 | Parts List .....                     | 43 |

## 1.0 Important Information and Warnings

### 1.1 Terms and Summary

This manual provides important information for personnel involved with the installation, operation and maintenance of this product. Although you may be familiar with this or similar equipment, it is strongly recommended that you read this manual before installing, operating, or maintaining the product.

#### Danger, Warning, Caution, and Notice

Throughout this manual there are steps and procedures that can present hazardous situations. The following signal words are used to identify the degree or level of hazard seriousness.

**⚠ DANGER** Danger indicates an imminently hazardous situation which, if not avoided, **will** result in **death or serious injury**, and property damage.

**⚠ WARNING** Warning indicates an imminently hazardous situation which, if not avoided, **could** result in **death or serious injury**, and property damage.

**⚠ CAUTION** Caution indicates a potentially hazardous situation which, if not avoided, **may** result **minor or moderate injury** or property damage.

**NOTICE** Notice is used to notify people of installation, operation, or maintenance information which is important but not directly hazard-related.

### ⚠ CAUTION

These general instructions deal with the normal installation, operation, and maintenance situations encountered with the equipment described herein. The instructions should not be interpreted to anticipate every possible contingency or to anticipate the final system, crane, or configuration that uses this equipment. For systems using the equipment covered by this manual, the supplier and owner of the system are responsible for the system's compliance with all applicable industry standards, and with all applicable federal, state, and local regulations/codes.

This manual includes instructions and parts information for a variety of hoist types. Therefore, all instructions and parts information may not apply to any one type or size of specific hoist. Disregard those portions of the instructions that do not apply.

Record your hoist's Code, Lot and Serial Number (see Section 9) on the front cover of this manual for identification and future reference to avoid referring to the wrong manual for information or instructions on installation, operation, inspection, maintenance, or parts.

Use only Harrington authorized replacement parts in the service and maintenance of this hoist.

## **WARNING**

Equipment described herein is not designed for and **MUST NOT** be used for lifting, supporting, or transporting people, or for lifting or supporting loads over people.

Equipment described herein should not be used in conjunction with other equipment unless necessary and/or required safety devices applicable to the system, crane, or application are installed by the system designer, system manufacturer, crane manufacturer, installer, or user.

Modifications to upgrade, rerate, or otherwise alter this equipment shall be authorized only by the original equipment manufacturer.

Equipment described herein may be used in the design and manufacture of cranes or monorails. Additional equipment or devices may be required for the crane and monorail to comply with applicable crane design and safety standards. The crane designer, crane manufacturer, or user is responsible to furnish these additional items for compliance. Refer to ANSI/ASME B30.17, "Safety Standard for Top-Running Single Girder Cranes"; ANSI/ASME B30.2 "Safety Standard for Top-Running Double-Girder Cranes"; and ANSI/ASME B30.11 "Safety Standard for Underhung Cranes and Monorails".

If a below-the-hook lifting device or sling is used with a hoist, refer to ANSI/ASME B30.9, "Safety Standard for Slings" or ANSI/ASME B30.20, "Safety Standard for Below-the-Hook Lifting Devices".

Hoists used to handle hot molten material may require additional equipment or devices. Refer to ANSI Z241.2, "Safety Requirements for Melting and Pouring of Metals in the Metalcasting Industry".

Failure to read and comply with any one of the limitations noted herein can result in serious bodily injury or death, and/or property damage.

## NOTICE

It is the responsibility of the owner/user to install, inspect, test, maintain, and operate a trolley or hoist in accordance with ANSI/ASME B30.16, "Safety Standard for Overhead Hoists", OSHA Regulations and ANSI/NFPA 70, "National Electric Code". If the trolley is installed as part of a total lifting system, such as an overhead crane or monorail, it is also the responsibility of the owner/user to comply with the applicable ANSI/ASME B30 volume that addresses that type of equipment.

It is the responsibility of the owner/user to have all personnel that will install, inspect, test, maintain, and operate a hoist read the contents of this manual and applicable portions of ANSI/ASME B30.16, "Overhead Hoists (Underhung)" and OSHA Regulations. If the trolley is installed as part of a total lifting system, such as an overhead crane, the applicable ANSI/ASME B30 volume that addresses that type of equipment must also be read by all personnel.

If the hoist owner/user requires additional information, or if any information in the manual is not clear, contact Harrington or the distributor of the hoist. Do not install, inspect, test, maintain, or operate this hoist unless this information is fully understood.

A regular schedule of inspection of the hoist in accordance with the requirements of ANSI/ASME B30.16 should be established and records maintained.

## 1.2 Warning Tags and Labels

The warning tag illustrated below in Figure 1-1 is supplied with each hoist shipped from the factory. If the tag is not attached to your hoist's no-load side of the load chain, order a tag from your dealer and install it. Read and obey all warnings attached to this hoist. Tag is not shown actual size.



English Version





Bilingual Version (shown larger for legibility)

Figure 1-1 Warning Tag Attached to Hoist

## 2.0 Technical Information

### 2.1 Specifications

#### 2.1.1 Product Code



#### 2.1.2 Operating Conditions and Environment

Temperature range: -4° to +140°F (-20° to +60°C)

Humidity: 100% or less (Not an Underwater Device)



**Table 2-1 NTH Trolley Hoist Specifications**


| Cap. (Tons) | Product Code |                | Headroom C (in) | Std. Lift (ft) | Pull to Lift Load (lbs) | Overhaul Ratio | Min. Radius for Curve (in) | *Flange Range B (in) | Load Chain Dia. (mm) x Chain Fall Lines | Push          |                               |                                     | Geared        |                               |  |
|-------------|--------------|----------------|-----------------|----------------|-------------------------|----------------|----------------------------|----------------------|---|---------------|-------------------------------|-------------------------------------|---------------|-------------------------------|--|
|             | Push Trolley | Geared Trolley |                 |                |                         |                |                            |                      |   | Net Wt. (lbs) | Shipping Weight Approx. (lbs) | Wt. for Addn'l One ft of Lift (lbs) | Net Wt. (lbs) | Shipping Weight Approx. (lbs) | Weight for Addn'l One ft of Lift (lbs) |
| 1           | NTH010       | G-NTH010       | 12.5            | 10             | 72                      | 31             | 39                         | 2.32-5.16            | 6.3x1                                   | 62            | 65                            | 1.2                                 | 73            | 78                            | 1.8                                    |
| 2           | NTH020       | G-NTH020       | 16.5            | 10             | 80                      | 63             | 47                         | 3.72-5.97            | 6.3x2                                   | 92            | 97                            | 1.8                                 | 103           | 110                           | 2.4                                    |
| 3           | NTH030       | G-NTH030       | 19.0            | 10             | 92                      | 81             | 59                         | 3.62-6.26            | 7.1x2                                   | 125           | 133                           | 2.1                                 | 136           | 177                           | 2.8                                    |
| 5           | NTH050       | G-NTH050       | 20.3            | 10             | 92                      | 134            | 79                         | 5.12-7.11            | 7.1x3                                   | 188           | 200                           | 2.9                                 | 199           | 240                           | 3.5                                    |

\* Other beam widths available. Consult factory.


\*NOTE: Any lift of chain is available on request. Simply specify the length of chain desired when ordering. Because Harrington chains are specially heat treated, only authentic Harrington chains should be used on your hoist. **NEVER** attempt to lengthen the chain by attaching additional chain links to it or by any other means.

## 2.2 Dimensions

**Table 2-2 NTH Trolley Hoist Dimensions**



| Cap. (Tons) | a (in) | a' (in) | b (in) | d (ft) | e (in) | e' (in) | f (ft) | g (in) | h (in) | i (in) | j (in) | k (in) | k' (in) | m (in) | n (in) | r (in) | t (in) |
|-------------|--------|---------|--------|--------|--------|---------|--------|--------|--------|--------|--------|--------|---------|--------|--------|--------|--------|
| 1           | 8.2    | 13.0    | 10.9   | 10.0   | 1.0    | 5.9     | 10.4   | 1.1    | 4.2    | 2.80   | 0.8    | 3.5    | 4.4     | 1.9    | 4.6    | 1.9    | 0.75   |
| 2           | 9.5    | 14.2    | 13.8   | 10.0   | 1.2    | 6.0     | 10.4   | 1.4    | 5.0    | 3.35   | 0.9    | 4.2    | 4.7     | 2.3    | 5.4    | 2.3    | 1.00   |
| 3           | 9.7    | 14.3    | 15.6   | 10.0   | 1.3    | 5.9     | 10.8   | 1.7    | 5.8    | 3.94   | 0.9    | 4.9    | 5.0     | 2.4    | 6.2    | 2.4    | 1.13   |
| 5           | 11.3   | 15.9    | 18.3   | 10.6   | 1.5    | 6.2     | 11.3   | 1.8    | 6.7    | 4.65   | 1.0    | 5.6    | 5.1     | 3.0    | 7.0    | 2.9    | 1.63   |


| Table 2-3 Bottom Hook Dimension*  |              |        |        |        |        |        |        |
|---|--------------|--------|--------|--------|--------|--------|--------|
|  <p style="text-align: center;">Figure 2-3</p> |              |        |        |        |        |        |        |
| Cap. (Tons)   | Product Code | a (in) | b (in) | c (in) | d (in) | e (in) | g (in) |
| 1   | NTH010       | 1.0    | 0.6    | 0.9    | 0.6    | 1.7    | 1.1    |
| 2   | NTH020       | 1.4    | 0.9    | 1.2    | 0.9    | 2.0    | 1.4    |
| 3   | NTH030       | 1.8    | 1.1    | 1.5    | 1.1    | 2.2    | 1.7    |
| 5   | NTH050       | 2.2    | 1.4    | 1.9    | 1.4    | 2.5    | 1.8    |

\*Refer to Section 5.7 for inspection dimensions and limits.

## 2.3 Optional Equipment

### 2.3.1 Optional Latch Lock Hooks


- The Bullard® hook has a conventional hook shape with a special, heavy-duty, rotating, spring-loaded, locking latch. The latch remains locked until it is released by the operator.
- The SmartLok™ hook is a special design hook where the latch remains fixed and the hook swings to unlock. The hook cannot be opened while a load is applied. *(Note: this type of hook was previously offered as a Shur-Loc®, but was replaced in 2022)*
- Installation of these hooks may change the headroom.
- See Section 9.2, Parts List for a complete Latch Lock Hook part listing.



### 2.3.2 Optional Inspection Hook


- The Inspection Hook is designed to facilitate the inspection of the internal surfaces of the hook yoke and shank portion of the hook itself. The Inspection Hook is suitable for applications where inspection of the internal parts of the hook set is required. The inspection hook uses the standard Harrington hook set and is assembled with high-strength locking fasteners instead of rivets. Inspection hooks are available in top and bottom versions. Refer to Figure 2-5.
- Disassembly and re-assembly involves removal and reinstallation of the yoke fasteners of the Inspection Hook Set Assembly followed by testing of the hoist prior to returning it to service.
- The Inspection Hook is available only for the NTH010 hoist.

- See Section 9.2, Parts List for a complete Inspection Hook part listing.



### 2.3.3 Optional Chain Containers

- Chain containers are sized based on the capacity and lift of the hoist. The containers are constructed from vinyl coated canvas with a steel frame on top. The containers are prepared differently depending on the hoist model. See Harrington document EDOC0154 using the appropriate CF hoist for sizing information.





**Table 3-1 Number of Adjusting Spacers**

| I-Beam Width | (in)      | 2 5/16 | 2 1/2   | 2 3/8 | 3   | 3 1/4 | 3 9/16 | 3 3/4 | 3 15/16 | 4   | 4 3/16 | 4 5/16 | 4 7/16 | 4 11/16 | 4 15/16 | 5     | 5 3/16 | 5 5/16 | 5 3/8 | 5 1/2 | 5 7/8 | 6     | 6 1/8 | 6 5/16 | 6 7/16 |     |     |     |
|--------------|-----------|--------|---------|-------|-----|-------|--------|-------|---------|-----|--------|--------|--------|---------|---------|-------|--------|--------|-------|-------|-------|-------|-------|--------|--------|-----|-----|-----|
|              |           | 2 3/8  | 2 15/16 | 75    |     | 82    | 90     | 98    | 100     | 102 | 106    | 110    | 113    | 119     | 125     | 127   | 131    | 135    | 137   | 143   | 149   | 153   | 155   | 160    | 163    |     |     |     |
| Cap.         | (mm)      | 58     | 64      | 73    | 76  | 82    | 90     | 91    | 98      | 100 | 102    | 106    | 110    | 113     | 119     | 120   | 125    | 127    | 131   | 135   | 137   | 143   | 149   | 150    | 153    | 155 | 160 | 163 |
| NTH010       | Inner     | 0      | 1+1     | 3+3   | 3+3 | 4+4   | 5+6    | 7+7   | 7+7     | 7+8 | 8+8    | 8+9    | 9+9    | 10+11   | 11+12   | 11+12 | 4+4    | 4+4    | 4+5   | 6+6   | 7+7   | 7+8   | 8+8   | 8+9    | 9+9    |     |     |     |
|              | Outer     | 24     | 22      | 18    | 18  | 16    | 13     | 10    | 10      | 9   | 8      | 7      | 6      | 3       | 1       | 1     | 16     | 16     | 15    | 12    | 10    | 9     | 8     | 7      | 6      |     |     |     |
| NTH020       | Inner     |        |         |       |     | 0+0   |        | 1+1   | 1+1     | 1+2 | 2+2    | 2+3    | 3+3    | 4+5     | 5+5     | 5+6   | 6+6    | 6+7    | 7+7   | 8+8   | 9+9   | 1+2   | 2+2   | 2+3    | 3+3    |     |     |     |
|              | Outer     |        |         |       |     | 18    |        | 16    | 16      | 15  | 14     | 13     | 12     | 9       | 8       | 7     | 6      | 5      | 4     | 2     | 0     | 15    | 14    | 13     | 12     |     |     |     |
| NTH030       | Inner     |        |         |       |     | 0+0   |        | 1+2   | 1+2     | 2+2 | 2+3    | 3+3    | 3+4    | 5+5     | 5+6     | 6+6   | 6+7    | 7+8    | 7+8   | 8+9   | 10+10 | 10+10 | 10+11 | 3+3    | 3+4    |     |     |     |
|              | Outer     |        |         |       |     | 22    |        | 19    | 19      | 18  | 17     | 16     | 15     | 12      | 11      | 10    | 9      | 7      | 7     | 5     | 2     | 2     | 1     | 16     | 15     |     |     |     |
| NTH050       | Inner (F) |        |         |       |     |       |        |       |         |     |        |        |        |         |         |       | 0+1    | 1+1    | 1+2   | 2+3   | 3+4   | 4+4   | 4+5   | 5+5    | 5+6    |     |     |     |
|              | Inner (R) |        |         |       |     |       |        |       |         |     |        |        |        |         |         |       | 1+2    | 2+2    | 2+3   | 3+4   | 4+5   | 5+5   | 5+6   | 6+6    | 6+7    |     |     |     |
|              | Outer     |        |         |       |     |       |        |       |         |     |        |        |        |         |         |       | 15     | 14     | 13    | 11    | 9     | 8     | 7     | 6      | 5      |     |     |     |



| I-Beam Width | (in)      | 6 11/16 | 6 3/8  | 7     | 7 1/16 | 7 1/4 | 7 3/8 | 8     | 8 7/16 | 8 11/16 | 9     | 9 3/8 | 9 3/4 | 10    | 10 3/8 | 10 1/4 | 10 3/8 | 10 1/2 | 11    | 11 3/8 | 11 1/4 | 11 3/8 | 11 3/4 | 11 13/16 |      |     |     |
|--------------|-----------|---------|--------|-------|--------|-------|-------|-------|--------|---------|-------|-------|-------|-------|--------|--------|--------|--------|-------|--------|--------|--------|--------|----------|------|-----|-----|
|              |           | 7 3/8   | 7 5/16 | 200   | 203    | 215   |       | 220   | 229    | 232     | 250   | 254   | 257   | 260   | 264    | 267    | 279    | 283    | 286   | 289    | 295    | 298    | 300    |          |      |     |     |
| Cap.         | (mm)      | 170     | 175    | 178   | 180    | 184   | 181   | 185   | 200    | 203     | 215   | 220   | 229   | 232   | 250    | 254    | 257    | 260    | 264   | 267    | 279    | 283    | 286    | 289      | 295  | 298 | 300 |
| NTH010       | Inner     | 10+10   | 11+11  | 11+12 | 12+12  | 4+5   | 7+7   | 7+8   | 9+9    | 10+10   | 11+12 | 12+12 | 7+7   | 7+8   | 8+8    | 8+9    | 9+9    | 9+10   | 11+12 | 12+12  | 4+4    | 4+5    | 5+6    | 6+7      | 6+7  |     |     |
|              | Outer     | 4       | 2      | 1     | 0      | 15    | 10    | 9     | 6      | 4       | 1     | 0     | 10    | 9     | 8      | 7      | 6      | 5      | 1     | 0      | 16     | 15     | 13     | 11       | 11   |     |     |
| NTH020       | Inner     | 4+4     | 5+5    | 5+6   | 6+6    | 6+7   | 9+9   | 1+2   | 3+3    | 4+4     | 5+6   | 6+6   | 9+9   | 1+2   | 2+2    | 2+3    | 3+3    | 3+4    | 5+6   | 6+6    | 6+7    | 7+7    | 8+8    | 8+9      | 8+9  |     |     |
|              | Outer     | 10      | 8      | 7     | 6      | 5     | 0     | 15    | 12     | 10      | 7     | 6     | 0     | 15    | 14     | 13     | 12     | 11     | 7     | 6      | 5      | 4      | 2      | 1        | 1    |     |     |
| NTH030       | Inner     | 4+5     | 5+6    | 6+6   | 6+7    | 7+8   | 9+10  | 10+10 | 3+4    | 4+5     | 6+6   | 6+7   | 9+10  | 10+10 | 10+11  | 11+11  | 3+4    | 4+4    | 6+6   | 6+7    | 7+7    | 7+8    | 8+9    | 9+9      | 9+10 |     |     |
|              | Outer     | 13      | 11     | 10    | 9      | 7     | 3     | 2     | 15     | 13      | 10    | 9     | 3     | 2     | 1      | 0      | 15     | 14     | 10    | 9      | 8      | 7      | 5      | 4        | 3    |     |     |
| NTH050       | Inner (F) | 6+7     | 7+8    | 8+8   | 0+0    | 1+1   | 3+4   | 4+4   | 5+6    | 6+7     | 8+8   | 0+0   | 3+4   | 4+4   | 4+5    | 5+5    | 5+6    | 6+6    | 8+8   | 0+0    | 0+1    | 1+2    | 2+3    | 3+3      | 3+3  |     |     |
|              | Inner (R) | 7+8     | 8+9    | 9+9   | 1+1    | 2+2   | 4+5   | 5+5   | 6+7    | 7+8     | 9+9   | 1+1   | 4+5   | 5+5   | 5+6    | 6+6    | 6+7    | 7+7    | 9+9   | 1+1    | 1+2    | 2+3    | 3+4    | 4+4      | 4+4  |     |     |
|              | Outer     | 3       | 1      | 0     | 16     | 14    | 9     | 8     | 5      | 3       | 0     | 16    | 9     | 8     | 7      | 6      | 5      | 4      | 0     | 16     | 15     | 13     | 11     | 10       | 10   |     |     |

| I-Beam Width | (in)      | 11 3/8 | 12    | 12 1/4 | 12 1/2 | 12 3/4 | 13    | 13 1/4 | 13 1/2 | 13 3/4 | 14    | 14 1/4 | 14 1/2 | 14 3/4 | 15    | 15 1/4 | 15 1/2 | 15 3/4 | 16    | 16 1/4 | 16 1/2 | 16 3/4 | 17  |  |  |
|--------------|-----------|--------|-------|--------|--------|--------|-------|--------|--------|--------|-------|--------|--------|--------|-------|--------|--------|--------|-------|--------|--------|--------|-----|--|--|
|              |           | 302    | 305   | 311    | 318    | 324    | 330   | 337    | 343    | 350    | 356   | 362    | 368    | 375    | 381   | 387    | 394    | 400    | 406   | 413    | 419    | 426    | 432 |  |  |
| Cap.         | (mm)      | 302    | 305   | 311    | 318    | 324    | 330   | 337    | 343    | 350    | 356   | 362    | 368    | 375    | 381   | 387    | 394    | 400    | 406   | 413    | 419    | 426    | 432 |  |  |
| NTH010       | Inner     | 7+7    | 7+8   | 8+9    | 9+10   | 10+11  | 11+12 | 4+4    | 5+5    | 6+7    | 7+8   | 8+9    | 9+10   | 10+11  | 11+12 |        |        |        |       |        |        |        |     |  |  |
|              | Outer     | 10     | 9     | 7      | 5      | 3      | 1     | 16     | 14     | 11     | 9     | 7      | 5      | 3      | 1     |        |        |        |       |        |        |        |     |  |  |
| NTH020       | Inner     | 9+9    | 1+2   | 2+3    | 3+4    | 4+5    | 5+6   | 6+7    | 7+8    | 8+9    | 1+2   | 2+3    | 3+4    | 4+5    | 5+6   | 6+7    | 7+8    | 8+9    |       |        |        |        |     |  |  |
|              | Outer     | 0      | 15    | 13     | 11     | 9      | 7     | 5      | 3      | 1      | 15    | 13     | 11     | 9      | 7     | 5      | 3      | 1      |       |        |        |        |     |  |  |
| NTH030       | Inner     | 9+10   | 10+10 | 11+11  | 4+4    | 5+5    | 6+6   | 7+7    | 8+8    | 9+9    | 10+10 | 11+11  | 4+4    | 5+5    | 6+6   | 7+7    | 8+8    | 9+9    | 10+10 | 11+11  |        |        |     |  |  |
|              | Outer     | 3      | 2     | 0      | 14     | 12     | 10    | 8      | 6      | 4      | 2     | 0      | 14     | 12     | 10    | 8      | 6      | 4      | 2     | 0      |        |        |     |  |  |
| NTH050       | Inner (F) | 3+4    | 4+4   | 5+5    | 6+6    | 7+7    | 8+8   | 0+1    | 1+2    | 3+3    | 4+4   | 5+5    | 6+6    | 7+7    | 8+8   | 0+1    | 1+2    | 3+3    | 4+4   | 5+5    | 6+6    | 7+7    | 8+8 |  |  |
|              | Inner (R) | 4+5    | 5+5   | 6+6    | 7+7    | 8+8    | 9+9   | 1+2    | 2+3    | 4+4    | 5+5   | 6+6    | 7+7    | 8+8    | 9+9   | 1+2    | 2+3    | 4+4    | 5+5   | 6+6    | 7+7    | 8+8    | 9+9 |  |  |
|              | Outer     | 9      | 8     | 6      | 4      | 2      | 0     | 15     | 13     | 10     | 8     | 6      | 4      | 2      | 0     | 15     | 13     | 10     | 8     | 6      | 4      | 2      | 0   |  |  |

## 3.2 Chain

- 3.2.1 **⚠️WARNING** Verify that the load chain is not twisted or tangled prior to operating the hoist. Make sure the bottom hook on the 2 (NTH020) through the 5 (NTH050) Ton multiple fall hoists is not capsized. See Figures 3-1 and 3-2. Correct all chain irregularities before conducting the first hoist operation.



### 3.3 Attachment Points & Mounting Location

3.3.1 **⚠ WARNING** Prior to attaching the hoist ensure that all attachment points, suspension components and supporting structure are adequate to support the hoist and its load. Prior to mounting the trolley (and hoist) ensure that the trolley beam and its supporting structure are adequate to support the trolley, hoist and its loads. If necessary consult a professional that is qualified to evaluate the adequacy of the suspension location and its supporting structure.

3.3.2 **NOTICE** See Section 6.6 for outdoor installation considerations.

### 3.4 Installation of Trolley onto Beam

3.4.1 Assemble and adjust the trolley before attempting to install the trolley on the beam.

3.4.2 Preferred Method – Sliding the trolley connected with an electric chain hoist onto the traversing beam from the beam end is the most convenient and recommended method. If the trolley can be mounted from the end of the beam then: Remove the trolley end-stop from the beam and set the trolley on the beam from the end. Securely re-install the trolley end stop on the beam.

3.4.3 Optional Method for Trolleys – If the trolley cannot be mounted from the end of the beam, complete the installation as follows:

- 1) Remove the Shaft Stopper Pin from Suspension Shaft (See Figure 3-1).
- 2) If possible remove the outside Adjusting spacers and Reinsert the Shaft Stopper Pin. Spread the trolley side plates apart.
- 3) Lift the trolley onto the beam so that Side Plate A rests on the beam's flange.
- 4) Hold Side Plate A securely so that it does not come off the beam then push the side plates together so that all four wheels rest on the beam's flange.
- 5) Replace the Outside Adjusting Spacers and the Shaft Stopper Pin. Insert Split Pin, Bend the Split Pin securely.

## 3.5 Preoperational Checks and Trial Operation

- 3.5.1 **⚠️ WARNING** Confirm the adequacy of the rated capacity for all slings, chains, wire ropes and all other lifting attachments before use. Inspect all load suspension members for damage prior to use and replace or repair all damaged parts.
- 3.5.2 **⚠️ WARNING** Verify and correct all chain irregularities prior to operating the hoist. Refer to Section 3.1.
- 3.5.3 Measure and record the “k” dimension of all hooks on hoist. See Table 5-4 under Section 5, “Inspection”.
- 3.5.4 Record the trolley-hoist's Code, Lot and Serial Number (from the name plate on the hoist; see Section 9) in the space provided on the cover of this manual.
- 3.5.5 Ensure that the hoist is properly installed to the trolley, the trolley is properly installed on the beam, and stops for the trolley are correctly positioned and securely installed on the beam.
- 3.5.6 Ensure that all nuts, bolts and split pins (cotter pins) are sufficiently fastened.
- 3.5.7 Confirm proper operation.
- Before operating read and become familiar with Section 4 - Operation.
  - Before operating ensure that the hoist meets the Inspection, Testing and Maintenance requirements of ANSI/ASME B30.16.
  - Before operating ensure that nothing will interfere with the full range of the trolley's and the hoist's operation.
- 3.5.8 Proceed with trial operation to confirm proper operation.
- Operate the trolley through its full range of motion. Make sure the trolley runs smoothly and does not bind.
  - Perform inspections per Section 5.3, “Frequent Inspections”.



## 4.0 Operation

### 4.1 Introduction

#### **DANGER**

DO NOT WALK UNDER A SUSPENDED LOAD

#### **WARNING**

HOIST OPERATORS SHALL BE REQUIRED TO READ THE OPERATION SECTION OF THIS MANUAL, THE WARNINGS CONTAINED IN THIS MANUAL, INSTRUCTION AND WARNING LABELS ON THE HOIST OR LIFTING SYSTEM, AND THE OPERATION SECTIONS OF ANSI/ASME B30.16 and ANSI/ASME B30.10. THE OPERATOR SHALL ALSO BE REQUIRED TO BE FAMILIAR WITH THE HOIST AND HOIST CONTROLS BEFORE BEING AUTHORIZED TO OPERATE THE HOIST OR LIFTING SYSTEM.

HOIST OPERATORS SHOULD BE TRAINED IN PROPER RIGGING PROCEDURES FOR THE ATTACHMENT OF LOADS TO THE HOIST HOOK.

HOIST OPERATORS SHOULD BE TRAINED TO BE AWARE OF POTENTIAL MALFUNCTIONS OF THE EQUIPMENT THAT REQUIRE ADJUSTMENT OR REPAIR, AND TO BE INSTRUCTED TO STOP OPERATION IF SUCH MALFUNCTIONS OCCUR, AND TO IMMEDIATELY ADVISE THEIR SUPERVISOR SO CORRECTIVE ACTION CAN BE TAKEN.

HOIST OPERATORS SHOULD HAVE NORMAL DEPTH PERCEPTION, FIELD OF VISION, REACTION TIME, MANUAL DEXTERITY, AND COORDINATION.

HOIST OPERATORS SHOULD **NOT** HAVE A HISTORY OF OR BE PRONE TO SEIZURES, LOSS OF PHYSICAL CONTROL, PHYSICAL DEFECTS, OR EMOTIONAL INSTABILITY THAT COULD RESULT IN ACTIONS OF THE OPERATOR BEING A HAZARD TO THE OPERATOR OR TO OTHERS.

HOIST OPERATORS SHOULD **NOT** OPERATE A HOIST OR LIFTING SYSTEM WHEN UNDER THE INFLUENCE OF ALCOHOL, DRUGS, OR MEDICATION.

#### **NOTICE**

- Read ANSI/ASME B30.16 and ANSI/ASME B30.10.
- Read the hoist manufacturer's Operating and Maintenance Instructions.
- Read all labels attached to equipment.

The operation of a hoist involves more than activating the hoist's controls. Per the ANSI/ASME B30 standards, the use of a hoist is subject to certain hazards that cannot be mitigated by engineered features, but only by the exercise of intelligence, care, common sense, and experience in anticipating the effects and results of activating the hoist's controls. Use this guidance in conjunction with other warnings, cautions, and notices in this manual to govern the operation and use of your hoist.

## 4.2 Shall's and Shall Not's for Operation

### **WARNING**

Improper operation of a hoist can create a potentially hazardous situation which, if not avoided, could result in death or serious injury, and substantial property damage. To avoid such a potentially hazardous situation **THE OPERATOR SHALL:**

- **NOT** lift more than rated load for the hoist.
- **NOT** use damaged hoist or hoist that is not working properly.
- **NOT** use hoist with twisted, kinked, damaged, or worn chain.
- **NOT** use hoist if the bottom hook is capsized (multiple fall hoists - see Section 3.1).
- **NOT** use the hoist to lift, support, or transport people.
- **NOT** lift loads over people.
- **NOT** apply load unless load chain is properly seated in the load sheave (and idle sheave for hoist with multiple chain falls).
- **NOT** use the hoist in such a way that could result in shock or impact loads being applied to the hoist.
- **NOT** attempt to lengthen the load chain or repair damaged load chain.
- **NOT** operate hoist when it is restricted from forming a straight line from hook to hook in the direction of loading.
- **NOT** use load chain as a sling or wrap load chain around load.
- **NOT** apply load if binding prevents equal loading on all load-supporting chains.
- **NOT** operate beyond the limits of the load chain travel.
- **NOT** support load on hook tip unless hook is designed for tip loading.
- **NOT** use in a way that causes either hook to be side-loaded.
- **NOT** leave load supported by the hoist unattended unless specific precautions have been taken.
- **NOT** allow the chain, or hook to be used as an electrical or welding ground.
- **NOT** allow the chain, or hook to be touched by a live welding electrode.
- **NOT** remove or obscure the warnings on the hoist.
- **NOT** operate a hoist on which the safety placards or decals are missing or illegible.
- Be familiar with operating controls, procedures, and warnings.
- Make sure the unit is securely attached to a suitable support before applying load.
- Make sure load slings or other approved single attachments are properly sized, rigged, and seated in the hook saddle.
- Take up slack carefully - make sure load is balanced and load-holding action is secure before continuing.
- Make sure all persons stay clear of the supported load.
- Protect the hoist's load chain from weld splatter or other damaging contaminants.
- Report Malfunctions or unusual performances (including unusual noises) of the hoist and remove the hoist from service until the malfunction or unusual performance is resolved.
- Warn personnel before lifting or moving a load.
- Warn personnel of an approaching load.

## CAUTION

Improper operation of a hoist can create a potentially hazardous situation which, if not avoided, could result in minor or moderate injury, or property damage. To avoid such a potentially hazardous situation **THE OPERATOR SHALL:**


- Maintain a firm footing or be otherwise secured when operating the hoist.
- Check brake function by tensioning the hoist prior to each lift operation.
- Use hook latches. Latches are to retain slings, chains, etc. under slack conditions only.
- Make sure the hook latches are closed and not supporting any parts of the load.
- Make sure the load is free to move and will clear all obstructions.
- Avoid swinging the load or hook.
- Make sure hook travel is in the same direction as shown on controls.
- Inspect the hoist regularly, replace damaged or worn parts, and keep appropriate records of maintenance.
- Use the hoist manufacturer's recommended parts when repairing the unit.
- Lubricate load chain per hoist manufacturer's recommendations.
- **NOT** use the hoist load limiting or warning device to measure load.
- **NOT** allow your attention to be diverted from operating the hoist.
- **NOT** allow the hoist to be subjected to sharp contact with other hoists, structures, or objects through misuse.
- **NOT** adjust or repair the hoist unless qualified to perform such adjustments or repair.

### 4.3 Hoist Operation

- 1) Face the hand chain wheel side of the hoist.
- 2) To raise the load, pull hand chain clockwise.
- 3) To lower the load, pull hand chain counterclockwise.

**NOTE:** The clicking sound of the pawl when a load is being raised indicates normal operation.

### 4.4 Trolley Operation

- 1) For Plain Trolley, movement is controlled by pushing/pulling on the load or the hook of the attached hoist.
- 2) For Geared Trolley, when facing Trolley Hand Wheel:
  - Pull down on the right side of Hand Chain (Clockwise Rotation) to move the Trolley left.
  - Pull down on the left side of Hand Chain (Counterclockwise Rotation) to move the Trolley right.
- 3)  **CAUTION** Avoid collisions with the end stops or other Trolleys. Damage may result.

## 5.0 Inspection

### 5.1 General

5.1.1 The inspection procedure herein is based on ANSI/ASME B30.16. The following definitions are from ANSI/ASME B30.16 and pertain to the inspection procedure below.

- **Designated Person** – a person selected or assigned as being competent to perform the specific duties to which he/she is assigned.
- **Qualified Person** – a person who, by possession of a recognized degree or certificate of professional standing, or who, by extensive knowledge, training, and experience, has successfully demonstrated the ability to solve or resolve problems relating to the subject matter and work.
- **Normal Service** – that distributed service which involves operation with randomly distributed loads within the rated load limit, or uniform loads less than 65% of rated load for not more than 15% of the time.
- **Heavy Service** – that service which involves operation within the rated load limit which exceeds normal service.
- **Severe Service** – that service which involves normal or heavy service with abnormal operating conditions.

### 5.2 Inspection Classification

5.2.1 Initial Inspection – prior to initial use, all new, altered, or modified hoists shall be inspected by a designated person to ensure compliance with the applicable provisions of this manual.

5.2.2 Inspection Classification – the inspection procedure for hoists in regular service is divided into two general classifications based upon the intervals at which inspection should be performed. The intervals in turn are dependent upon the nature of the critical components of the hoist and the degree of their exposure to wear, deterioration, or malfunction. The two general classifications are herein designated as FREQUENT and PERIODIC, with respective intervals between inspections as defined below.

5.2.3 FREQUENT Inspection – visual examinations by the operator or other designated personnel with intervals per the following criteria:

- Normal service – monthly
- Heavy service – weekly to monthly
- Severe service – daily to weekly
- Special or infrequent service – as recommended by a qualified person before and after each occurrence.

5.2.4 PERIODIC Inspection – visual inspection by a designated person with intervals per the following criteria:

- Normal service – yearly
- Heavy service – semiannually
- Severe service – quarterly
- Special or infrequent service – as recommended by a qualified person before the first such occurrence and as directed by the qualified person for any subsequent occurrences.

### 5.3 Frequent Inspection

- 5.3.1 Inspections should be made on a FREQUENT basis in accordance with Table 5-1, "Frequent Inspection." Included in these FREQUENT Inspections are observations made during operation for any defects or damage that might appear between Periodic Inspections. Evaluation and resolution of the results of FREQUENT Inspections shall be made by a designated person such that the hoist is maintained in safe working condition.

| <b>Table 5-1 Frequent Inspection</b>   |
|--|
| All functional operating mechanisms for proper operation and adjustment, maladjustment and unusual sounds. |
| Hoist braking system for proper operation  |
| Hooks and latches in accordance with ANSI/ASME B30.10  |
| Hook latch operation   |
| Load chain in accordance with Section 5.7  |
| Load chain reeving for compliance with Section 3.1 and 6.4   |
| Hoist support for damage   |
| Connection points between Hoist and Trolley in accordance with ANSI/ASME B30.16                            |

### 5.4 Periodic Inspection

- 5.4.1 Inspections should be made on a PERIODIC basis in accordance with Table 5-2, "Periodic Inspection." Evaluation and resolution of the results of PERIODIC Inspections shall be made by a designated person such that the hoist is maintained in safe working condition.
- 5.4.2 For inspections where load suspension parts of the hoist are disassembled, a load test per ANSI/ASME B30.16 must be performed on the hoist after it is re-assembled and prior to its return to service.

| <b>Table 5-2 Periodic Inspection</b>  |
|---|
| Requirements of frequent inspection.  |
| Evidence of loose bolts, nuts, pins, or rivets.   |
| Evidence of worn, corroded, cracked, or distorted parts such as load blocks, suspension housing, chain attachments, clevises, yokes, suspension bolts, shafts, gears, bearings, pins, rollers, locking and clamping devices, wheels, and bumpers. |
| Evidence of damage to hook retaining nuts or collars and pins, and welds or rivets used to secure the retaining members.  |
| Evidence of damage or excessive wear of load and idler sheaves.   |
| Evidence of worn, glazed or oil contaminated friction disks; worn pawls, cams or ratchet; corroded, stretched, or broken pawl springs in brake mechanism.   |
| Evidence of damage to supporting structure.   |
| Function label on hoist for legibility.   |
| Warning label properly attached to the hoist and legible (see Section 1.2).   |
| End connection of load chain.   |

## 5.5 Occasionally Used Hoists

5.5.1 Trolley-hoists that are used infrequently shall be inspected as follows prior to placing in service:

- Trolley-hoist Idle More Than 1 Month, Less Than 1 Year: Inspect per FREQUENT Inspection criteria in Section 5.3.
- Trolley-hoist Idle More Than 1 Year: Inspect per PERIODIC Inspection criteria in Section 5.4.

## 5.6 Inspection Records

5.6.1 Dated inspection reports and records should be maintained at time intervals corresponding to those that apply for the trolley-hoist's PERIODIC interval per Section 5.2.4. These records should be stored where they are available to personnel involved with the inspection, maintenance, or operation of the hoist.

5.6.2 A long range chain inspection program should be established and should include records of examination of chains removed from service so a relationship can be established between visual observation and actual condition of the chain.

## 5.7 Inspection Methods and Criteria

5.7.1 This section covers the inspection of specific items. The list of items in this section is based on those listed in ANSI/ASME B30.16 for the Frequent and Periodic Inspection.

5.7.2 Frequent Inspection - Not intended to involve disassembly of the hoist. Disassembly for further inspection would be required if only if frequent inspection results so indicate. Disassembly and further inspection should only be performed by a qualified person trained in the disassembly and re-assembly of the hoist.

5.7.3 Periodic Inspection - Disassembly of the hoist is required. Disassembly should only be performed by a qualified person trained in the disassembly and re-assembly of the hoist.

5.7.4 In accordance with ANSI/ASME B30.16, these inspections are not intended to involve disassembly of the trolley. Rather, disassembly for further inspection would be required if frequent or periodic inspection results so indicate. Such disassembly and further inspection should only be performed by a qualified person trained in the disassembly and re-assembly of the trolley.

**Table 5-3 Hoist Inspection Methods and Criteria**

| Item                             | Method           | Discard Limit/Criteria  | Action                         |
|----------------------------------|------------------|---|--------------------------------|
| Functional operating mechanisms. | Visual, Auditory | Mechanisms should be properly adjusted and should not produce unusual sounds when operated. Components should not be deformed, scarred, or show significant wear. Refer to Figures 5-2, 5-3 and 5-4.                              | Repair or replace as required. |
| Hook – Stretch                   | Measure          | The "k" dimension should not be greater than 1.05 times that measured and recorded at the time of purchase (See Section 3.4). If recorded "k" values are not available for hooks when new, use nominal "k" values from Table 5-4. | Replace.                       |
| Hook – Fretting wear             | Measure          | The "u" and "t" dimensions should not be less than discard value listed in Table 5-4.   | Replace.                       |
| Hook – Surface Condition         | Visual           | Should be free of gouges, deep nicks, dents, weld splatter, and significant corrosion.  | Replace.                       |
| Hook – Deformation               | Visual           | Should be free of twists and deformations. See Figure 5-1.  | Replace.                       |
| Hook – Bent Shank or Neck        | Visual           | Shank and neck portions of hook should be free of deformations.   | Replace.                       |


| <b>Table 5-3 Hoist Inspection Methods and Criteria</b> |                  |   |  |
|--|------------------|---|--|
| <b>Item</b>  | <b>Method</b>    | <b>Discard Limit/Criteria</b>   | <b>Action</b>  |
| Hook – Swivel  | Visual, Function | Bearing parts and surfaces should not show significant wear, and should be free of dirt, grime, and deformations. Hook should rotate freely with no roughness. See Figure 5-1.  | Clean/lubricate, or replace as required.                                 |
| Hook – Yoke Assembly                                   | Visual           | Should be free of significant rust, weld splatter, nicks, and gouges. Holes should not be elongated, fasteners should not be loose, and there should be no gap between mating parts.  | Tighten or replace as required.  |
| Hook – Idle Sheave and Shaft (Multiple Fall Hoist)     | Visual, Function | Pockets of Idle Sheave should be free of significant wear. Idle Sheave surfaces should be free of nicks, gouges, dirt, and grime. Bearing parts and surfaces of Idle Sheave and Axle should not show significant wear. Idle Sheave should rotate freely with no roughness or significant free play. | Clean/lubricate, or replace as required.                                 |
| Hook – Hook Latches                                    | Visual, Function | Latch should not be deformed. Attachment of latch to hook should not be loose. Latch spring should not be missing and should not be weak. Latch movement should not be stiff - when depressed and released latch should snap smartly to its closed position.  | Replace.   |
| Yoke – Top Pin Hole Deformation                        | Visual, Measure  | The "d" dimension of the top pin hole should not be greater than the discard value listed in Table 5-5.   | Replace Hook Set   |
| Top Pin – Deformation                                  | Visual, Measure  | The pin should be free of scars or significant deformation. The "d" dimension should not be less than discard value listed in Table 5-6.  | Replace  |
| Yoke – Chain Pin Hole Deformation                      | Measure          | The "d" dimension of the chain pin hole should not be greater than the discard value listed in Table 5-5.   | Replace Hook Set or yoke.  |
| Chain Pin – Deformation                                | Visual, Measure  | The pin should be free of scars or significant deformation. The "d" dimension should not be less than discard value listed in Table 5-7.  | Replace  |
| Load Chain – Pitch and Wire Diameter                   | Measure          | The "P" dimension should not be greater than discard value listed in Table 5-5. The "d" dimension should not be less than discard value listed in Table 5-8.  | Replace. Inspect Load Sheave (and Idle Sheave for multiple fall hoists). |
| Load Chain – Surface Condition                         | Visual           | Should be free of gouges, nicks, dents, weld splatter, and corrosion. Links should not be deformed, and should not show signs of abrasion. Surfaces where links bear on one another should be free of significant wear.   | Replace.   |
| Load Chain – Lubrication                               | Visual, Auditory | Entire surface of each chain link should be coated with lubricant and should be free of dirt and grime. Chain should not emit cracking noise when hoisting a load.  | Clean/lubricate (see Section 6.0).                                       |

**Table 5-3 Hoist Inspection Methods and Criteria**

| Item                              | Method                     | Discard Limit/Criteria  | Action                                   |
|-----------------------------------|----------------------------|---|--|
| Load Chain – Reeving              | Visual                     | Chain should be reeved properly through Load Sheave. On multiple fall hoists chain should be installed properly and free of twists. Refer to Section 3.2.   | Reeve/Install chain properly.            |
| Lifting System – Components       | Visual, Function           | Components should not be deformed, scarred, or show significant wear.   | Replace.                                 |
| Braking System – Components       | Visual                     | Brake Pawl, Pawl Pin, and Pawl Spring should not be deformed, scarred, or show significant wear. Refer to Figure 5-2 (27, 24, & 26).  | Replace.                                 |
| Brake – Damage to Brake Surface   | Visual                     | Damage due to scratching or gouging by foreign matter. Refer to Figure 5-2 (32, 30, & 33).  | Replace.                                 |
| Braking System – Friction Disc    | Visual                     | The surface of the friction plate should be free of scars, gouges, and wear. Refer to Figure 5-2 (29).  | Replace.                                 |
| Braking System – Friction Plate   | Visual, Measure            | The surface of the friction plate should be free of grease, oil, scars, gouges and wear and have uniform thickness. The outer thickness should not be thinner than the inner thickness. The thickness should not be less than the discard value listed in Table 5-9.  | Replace.                                 |
| Braking System – Bushing          | Measure                    | The bushing should have uniform thickness. The “t” dimension should not be less than the discard value listed in Table 5-10.  | Replace.                                 |
| Braking System – Bushing          | Visual                     | When slightly heated, the bushing should be so lubricated that lubricant oozes off the surface. Refer to Figure 5-2 (31). Type of oil to be used: ISO VG68 or equivalent.   | Soak bushing in machine oil for one day. |
| Braking System – Ratchet Disc     | Measure                    | The “D” dimension should not be less than the discard value listed in Table 5-11. Refer to Figure 5-2 (30).   | Replace.                                 |
| Load Sheave                       | Visual                     | Pockets of Load Sheave should be clean and free of significant wear. Refer to Figure 5-3 (18).  | Replace.                                 |
| Load Gear                         | Visual                     | Teeth have excessive wear or damage. Refer to Figure 5-4 (19).  | Replace.                                 |
| Hand Wheel                        | Visual                     | Large wear or deformation on the surface of hand wheel. The hand wheel touches the cover.   | Replace.                                 |
| Housing and Mechanical Components | Visual, Auditory, Function | Trolley-hoist components including suspension shafts, track wheels, track wheel axles, load blocks, suspension housing, chain attachments, clevises, yokes, suspension bolts, shafts, gears, bearings, stripper, pins, rollers, and bumpers should be free of cracks, distortion, significant wear, and corrosion. Evidence of same can be detected visually or via detection of unusual sounds during operation. | Replace.                                 |
| Chain Guide                       | Visual                     | Excessive wear or press mark.   | Replace.                                 |





| Table 5-3 Hoist Inspection Methods and Criteria |                                |   |                                 |
|---|--------------------------------|---|---------------------------------|
| Item  | Method                         | Discard Limit/Criteria  | Action                          |
| Bolts, Nuts and Rivets                          | Visual, Check with Proper Tool | Bolts, nuts, snap rings, split pins, and rivets should not be loose, deformed, or corroded.                     | Tighten or replace as required. |
| Side Plates                                     | Visual                         | Must be free of significant deformation   | Replace.                        |
| Track Wheel - Tread                             | Visual, Measure                | Diameter of the inside and outside tread surface should not be less than the discard value shown in Table 5-12. | Replace.                        |
| Track Wheel - Gear                              | Visual                         | Teeth should not be cracked, damaged, or excessively worn.  | Replace.                        |
| Suspension Shaft                                | Visual, Measure                | Suspension shaft should not be bent. Diameter should not be worn by 10% or more.                                | Replace.                        |
| Warning Labels                                  | Visual                         | Warning Labels should be affixed to the hoist (see Section 1.2) and they should be legible.                     | Replace.                        |
| Trolley-Hoist Capacity Label                    | Visual                         | The label that indicates the capacity of the hoist should be legible and securely attached to the hoist.        | Replace.                        |





| Table 5-4 Top Hook & Bottom Hook Dimensions     |                                     |                            |             |                            |             |
|---|-------------------------------------|----------------------------|-------------|----------------------------|-------------|
| <p>"k" Measured When New:<br/>Bottom: _____</p> |                                     |                            |             |                            |             |
| Product Code                                    | Nominal "k" Dimension*<br>inch (mm) | "u" Dimension<br>inch (mm) |             | "t" Dimension<br>inch (mm) |             |
|   |                                     | Standard                   | Discard     | Standard                   | Discard     |
| NTH010  | 1.92 (48.8)                         | 0.86 (21.8)                | 0.79 (20.0) | 0.63 (16.0)                | 0.57 (14.4) |
| NTH020  | 2.36 (59.9)                         | 1.18 (30.0)                | 1.06 (27.0) | 0.87 (22.0)                | 0.78 (19.8) |
| NTH030  | 2.72 (69.1)                         | 1.48 (37.5)                | 1.34 (34.0) | 1.06 (27.0)                | 0.96 (24.3) |
| NTH050  | 3.06 (77.8)                         | 1.87 (47.5)                | 1.69 (43.0) | 1.38 (35.0)                | 1.24 (31.5) |


\* These values are nominal since the dimension is not controlled to a tolerance. The "k" dimension should be measured when the hook is new - this becomes a reference measurement. Subsequent measurements are compared to this reference to make determinations about hook deformation/stretch. See Section 5.7, "Hooks - Stretch".

| Table 5-5 Chain Pin Hole and Top Pin Hole Wear Dimensions                         |                             |             |                           |              |
|---|-----------------------------|-------------|---------------------------|--------------|
|  |                             |             |                           |              |
| Product Code  | Hole Diameter (d)           |             |                           |              |
|   | Chain Pin Hole<br>inch (mm) |             | Top Pin Hole<br>inch (mm) |              |
|   | Standard                    | Discard     | Standard                  | Discard      |
| NTH010, NTH020  | 0.319 (8.1)                 | 0.339 (8.6) | 0.480 (12.2)              | 0.500 (12.7) |
| NTH030, NTH050  | 0.350 (8.9)                 | 0.370 (9.4) | 0.638 (16.2)              | 0.658 (16.7) |

| Table 5-6 Body Top Pin Wear Dimensions  |                            |            |
|---|----------------------------|------------|
|  |                            |            |
| Product Code  | "d" Dimension<br>inch (mm) |            |
|   | Standard                   | Discard    |
| NTH010, NTH020  | 0.472 (12)                 | 0.433 (11) |
| CF030, CF050  | 0.630 (16)                 | 0.591 (15) |

| Table 5-7 Chain Pin Wear Dimensions   |                            |             |
|---|----------------------------|-------------|
|  |                            |             |
| Product Code  | "d" Dimension<br>inch (mm) |             |
|   | Standard                   | Discard     |
| NTH010, NTH020  | 0.311 (7.9)                | 0.295 (7.5) |
| NTH030, NTH050  | 0.343 (8.7)                | 0.327 (8.3) |

| Table 5-8 Chain Wear Dimensions   |                            |              |                            |            |
|---|----------------------------|--------------|----------------------------|------------|
|  |                            |              |                            |            |
| Product Code  | "P" Dimension<br>inch (mm) |              | "d" Dimension<br>inch (mm) |            |
|   | Standard                   | Discard      | Standard                   | Discard    |
| NTH010, NTH020  | 3.76 (95.5)                | 3.85 (97.9)  | 0.25 (6.3)                 | 0.22 (5.7) |
| NTH030, NTH050  | 4.18 (106.2)               | 4.29 (108.9) | 0.28 (7.1)                 | 0.26 (6.5) |



**Table 5-9 Friction Plate Wear Dimensions**


| Product Code | Thickness<br>inch (mm) |             |
|--------------|------------------------|-------------|
|              | Standard               | Discard     |
| All          | 0.118 (3.0)            | 0.098 (2.5) |



**Table 5-10 Brake Bushing Wear Dimensions**

**Bushing [31]**  
t: Radial thickness


| Product Code                  | A Dimension<br>inch (mm) |             |
|-------------------------------|--------------------------|-------------|
|                               | Standard                 | Discard     |
| CF010, CF020,<br>CF030, CF050 | 0.157 (4.0)              | 0.118 (3.0) |

**Table 5-11 Brake Ratchet Disc Wear Dimensions**

|  |                          |            |
|---|--------------------------|------------|
| Product Code  | D Dimension<br>inch (mm) |            |
|   | Standard                 | Discard    |
| CF010, CF020,<br>CF030, CF050   | 3.858 (98)               | 3.740 (95) |



**Table 5-12 Track Wheel Wear Dimensions**



Note: Track wheels are for flat and tapered flanges.


| Capacity<br>(Ton) | "D" Dimension<br>inch (mm) |             | "t" Dimension<br>inch (mm) |              | "r" Dimension<br>inch (mm) |             |
|-------------------|----------------------------|-------------|----------------------------|--------------|----------------------------|-------------|
|                   | Standard                   | Discard     | Standard                   | Discard      | Standard                   | Discard     |
| 1                 | 2.80 (71)                  | 2.74 (69.5) | 0.374 (9.5)                | 0.264 (6.7)  | 0.224 (5.7)                | 0.158 (4.0) |
| 2                 | 3.35 (85)                  | 3.29 (83.5) | 0.413 (10.5)               | 0.291 (7.4)  | 0.232 (5.9)                | 0.161 (4.1) |
| 3                 | 3.94 (100)                 | 3.88 (98.5) | 0.453 (11.5)               | 0.319 (8.1)  | 0.260 (6.6)                | 0.181 (4.6) |
| 5                 | 4.65 (118)                 | 4.41 (112)  | 0.591 (15.0)               | 0.413 (10.5) | 0.370 (9.4)                | 0.260 (6.6) |

## 6.0 Maintenance and Handling

### 6.1 Lubrication

#### 6.1.1 Load Chain

- For longer life, the load chain should be lubricated.
- The load chain lubrication should be accomplished after cleaning the load chain with an acid free cleaning solution.
- Apply Harrington lubricating grease (Part No. ER2CS1951) or an equivalent to industrial general lithium grease, NLGI No. 0, to the bearing surfaces of the load chain links as indicated by the shaded areas in Figure 6-1. Also apply the grease to the areas of the load chain (shaded areas in Figure 6-1) that contact the load sheave. Insure that the grease is applied to the contact areas in the load sheave pockets.
- Machine or gear oil (grade ISO VG 46 or 68 oil or equivalent) may be used as an alternative lubricant but must be applied more frequently.



- The chain should be lubricated every 3 months (more frequently for heavier usage or severe conditions).
- For dusty environments, it is acceptable to substitute a dry lubricant.

#### 6.1.2 Hooks and Suspension Components:

- Hooks – Bearings should be cleaned and lubricated at least once per year for normal usage. Clean and lubricate more frequently for heavier usage or severe conditions.
- Suspension Pins - Lubricate the chain pin and the top pin at least twice per year for normal usage; more frequently for heavier usage or severe conditions.

#### 6.1.3 Applying Grease to Hoist Gears:

- Remove body B as instructed in Section 6.3.
- Remove old grease and replace the new grease (NLGI No. 2), at annual inspection.
- Temperature range of standard grease is -20°C (-4°F) to + 60°C (140°F). If the hoist is used at temperatures below -20°C (-4°F) or above 60°C (140°F), consult the manufacturer or dealer since some parts should be changed.

| <b>Table 6-1 General Lubrication</b>  |                        |  |  |
|---|------------------------|--|--|
| <b>Parts to be Lubricated</b>   | <b>Name of Oil</b>     | <b>Amount of Lubrication and Lubricating Method</b>                | <b>Frequency of Lubrication</b>                                    |
| Mechanical Brake Parts:<br>Ratchet Disc, Pawl Pin,<br>Screw parts of Pinion | Machine or<br>Gear Oil | Wipe off oil with waste cloth after applying proper amount of oil. | When the hand pull becomes extremely heavy in lowering operations. |

6.1.4 Trolley:

- Lubricate the following trolley components with NLGI (National Lubricating Grease Institute) #2 or equivalent grease.
- Track Wheel Gear – Clean and re-grease the Track Wheel gears and Hand Wheel output pinion every three months (more frequently for heavier usage or severe conditions). Do not use an excessive amount of grease and avoid getting any grease on the running surfaces of the Track Wheels or the beam.
- Trolley Wheel Bearings do not need to be lubricated and must be replaced if worn or damaged.
- Suspension Pins, Bolts and Shafts – Grease at least twice per year for normal usage (more frequently for heavier usage or severe conditions).

## 6.2 Disassembly, Assembly and Adjustment

### 6.2.1 **NOTICE**

- 1) Perform proper disassembly or assembly in accordance with this manual.
- 2) The hoist utilizes dry friction plates; they are not to be lubricated.
- 3) Do not extend the load chain.
- 4) Remove old grease on the disassembled parts.
- 5) Replace components with Harrington Hoist approved parts.
- 6) To reassemble, apply new grease, and use a new split pin and snap ring.

6.2.2 Tools – The following tools are required to disassemble/reassemble the hoist.

| No. | Tool                             | Operation              |
|-----|----------------------------------|------------------------|
| 1   | Snap ring pliers                 | Opening a snap ring    |
| 2   | Metric socket wrenches           | Slotted nuts           |
| 3   | Metric hex keys (Allen wrenches) | Socket head cap screws |
| 4   | Metric wrenches                  | Bolts and nuts         |
| 5   | Phillips screwdriver             | Machine screws         |
| 6   | Pliers (Needle Nose)             | Split pins             |
| 7   | Soft-face (Dead blow) hammer     |                        |
| 8   | Wooden Blocks                    | Elevate hoist          |

## 6.3 Hoist Disassembly

Proceed as follows (**Note: Figures in brackets are Figure Numbers in Parts List**):

- 1) Orient a hoist with wheel cover side up.
- 2) Unscrew three screws [38] (with spring washers [39]) that attach the wheel cover [37].
- 3) Remove the wheel cover [37] from the body A [10].
- 4) Insert a vertical link of the hand chain [43] into the notch of the hand wheel [33] and remove the hand chain by turning the hand wheel counterclockwise.

**NOTE:** Bring the notch of the hand wheel to the right hand side.

- 5) Pull out split pin [36] from the wheel stopper pin [35] and remove the wheel stopper pin and wheel stopper [34] from the pinion [14].
- 6) Remove the hand wheel [33] from the pinion [14] by turning the hand wheel counterclockwise.  
**NOTE:** If the hand wheel is too tight to turn by hand, put hand chain on the hand wheel again and pull it down hard. It will release the brake.
- 7) Remove two friction plates [32], ratchet disc [30] and bushing [31] from the friction disc [29].
- 8) Remove the friction disc [29] from the pinion [14] by turning counterclockwise holding the end of the pinion with your fingers.
- 9) Remove snap ring [28] from the pawl pin [24] (on the body A [10]) and then remove pawl [27] and pawl spring [26].
- 10) Unscrew the pawl pin [24].  
**NOTE:** The pawl pin is fixed with the U nut [25].
- 11) Unscrew four socket bolts [22, 22-A] connecting body A [10] and B [11].  
**NOTE:** Four socket bolts are fixed with U nuts [23] on the body B side.
- 12) Separate the body A [10] and B [11].
- 13) Take ball bearing A [15] and C [17-A] out of the body A [10] (only if bearing needs replaced).
- 14) Remove the suspender and top pin [3] from the body B [11].
- 15) Remove pinion [14], chain guide [20] (or guide rollers [20-A]), stripper [21], tail pin [40], and load chain [42].
- 16) Remove the frame [13].
- 17) Take load sheave [18] out of the load gear [19].
- 18) Remove the load gear [19].
- 19) Unscrew tap socket bolt [41] from the body B [11].
- 20) Pull split pin [9] out of the slotted nut [8] and remove the slotted nut and chain pin [7] from the bottom hook [4].

## 6.4 Hoist Assembly

6.4.1

### **⚠ WARNING**


- Inspect and replace any worn or damaged parts per Table 5-3.
- Secure all nuts, bolts and split pins firmly.
- Replace all split pins and retaining rings.

6.4.2

Assembly


- 1) Wipe off old grease from the body B [11] and frame [13].
- 2) Apply new grease to the ball bearing B [16] and C [17] on the body B [11].
- 3) Insert load sheave [18] into the load gear [19] and put them together on the ball bearing C [17].






- 4) Apply new grease to the load gear [19].
- 5) Put frame [13] on the body B [11] according to pattern.
- 6) Insert the end of the load chain [42] to the bottom hook [4] and fix them with the chain pin [7], slotted nut [8] and split pin [9].

**⚠ WARNING** : Always bend the split pin securely.



- 7) Place the load chain [42] on the load sheave [18] so that the bottom hook side comes to right hand and the end link of the other side becomes vertical to the load sheave pocket.

**⚠ WARNING** : Put the welded part of the vertical chain link outward.




8) Put chain guide [20] (or guide rollers for ½ ton [20-A]) on the frame [13].

**⚠ WARNING** : Fit the larger boss of chain guide [20] into holes on frame [13].

9) Put stripper [21] on the frame [13].

10) Insert pinion [14] shaft from its gear side through the frame [13] and into ball bearing B [16].

11) Insert top pin [3] into the frame [13] and put suspender to the top pin.




12) Clean and grease ball bearing A [15] and D [17-A] and insert into body A [10] (if being replaced).

13) Put the body A [10] with the ball bearings [15, 17-A] side down on the body B [11].

**⚠ WARNING** : Make sure each part is completely set between body A [10] and frame [13].

14) Insert four socket bolts [22, 22-A] into the body A [10] and turn the whole body sideways. Then fix the bolts with the U nuts [23] holding the U nuts with fingers.

**⚠ WARNING** : Insert short socket bolts [22-A] to the upper holes and long socket bolts [22] to the lower holes.



- 15) Insert pawl pin [24] into the body A [10] and fix it with the U nut [25].
- 16) Apply machine oil to the pawl pin [24] and join pawl spring [26] and the pawl [27] respectively to it. Fix the pawl with snap ring [28].


**⚠ WARNING** : Make sure the pawl spring is fixed to the pawl and the snap ring is securely set at the groove of the pawl pin.

- 17) Thread friction disc [29] on the pinion [14].

- 18) Wipe out any dirt on the friction disc [29], friction plates [32] and both sides of the ratchet disc [30] and make sure that bushing [31] is properly soaked with oil. Then place the friction plate, bushing, ratchet disc (while the pawl [27] is rotated counterclockwise), and friction plate respectively on the friction disc. (Make sure that the pawl meshes with the ratchet disc properly.)

**⚠ WARNING** : **NEVER** apply oil since the brake is a "dry system". Thoroughly wipe out any oil and dirt on the brake. The gear of the ratchet should point at the pawl. Otherwise, the hand wheel cannot be assembled later.

In case the bushing does not have oil inside, soak it in turbine oil for a day. Install it without wiping the oil. Make sure that the pawl meshes with the ratchet disc properly.




- 19) Remove the dirt from the hand wheel [33] and apply machine oil to the threaded part. Assemble onto the pinion shaft [14] by turning it clockwise as far as possible.
- 20) Place wheel stopper [34] on the head of the pinion [14], insert wheel stopper pin [35] and fix it with a split pin [36].

**⚠ WARNING** : NEVER forget to bend the split pin after inserting into the wheel stopper pin.

- 21) Set the notch of the hand wheel to the left hand side. Insert the vertical link of the hand chain [43] into the notch of the hand wheel [33] and reeve the hand chain by turning the hand wheel clockwise.


**NOTE:** Make sure welds on hand chain are to the outside of the hand wheel.



**Figure 6-8 Hand Wheel Assembly**

- 22) Put wheel cover [37] on the body A [10] and fix them with the spring washers [39] and screws [38].
- 23) Put a hoist with body B [11] side up. Place the slack end of the load chain between body A [10] and body B [11]. Then insert tail pin [40], and screw tap socket bolt [41] into the body B.

**⚠ WARNING** : Make sure the load chain is not twisted. Be careful not to cross thread or over torque tap socket bolt [41].



**Figure 6-9 Body "B" Assembly**

| <b>Cap. (Tons)</b> | <b>Product Code</b> | <b>Bottom Bullard®</b> | <b>Bottom Shur-loc®</b> | <b>Bottom Inspection</b> | <b>Bottom SmartLok™</b> |
|--------------------|---------------------|------------------------|-------------------------|--------------------------|-------------------------|
| 1                  | CF010               | 55                     | 55                      | 55                       |                         |
| 2                  | CF020               | 199                    | 199                     |                          | 199                     |
| 3                  | CF030               | 398                    | 398                     |                          | 398                     |
| 5                  | CF050               | 398                    | 398                     |                          | 398                     |

## 6.5 Storage

6.5.1 **⚠ WARNING** : **IMPROPER** chain hoist use could result in death or serious injury. To avoid these hazards:

- **ALWAYS** store the hoist in a no load condition.
- **ALWAYS** wipe off all dirt and water.
- **ALWAYS** oil the chain, hook pins and hook latches.
- **ALWAYS** hang in a dry place.
- **ALWAYS** check the hoist for abnormalities (according to the regular inspection procedures) when using the hoist after a period of non-use (Refer to section 5.5).

## 6.6 Outdoor Installation

- 6.6.1 For hoist installations that are outdoors, the hoist should be covered or brought inside when not in use.
- 6.6.2 Possibility of corrosion on components of the hoist increases for installations where salt air and high humidity are present. Make frequent and regular inspections of the hoist's condition and operation

## 7.0 Troubleshooting




### **⚠ WARNING**

Read and comply with instructions in this manual and use the hoist properly.  
 Checking the sounds from the hoist in operation is a critical inspection. Note hoist sounds during operation.  
 If a defect is found in the hoist, stop using it immediately and check the cause of the defect.  
 Only Trained and competent personnel should inspect and repair the hoist.



**Table 7-1 Troubleshooting Guide**

Note on proper operation:

- When lifting, the hoist should make clicking sounds when moving the hand wheel.
- When lowering, the hoist should not make clicking sounds when moving the hand wheel.


| Symptom  | Cause  | Remedy  |
|--|--|---|
| Hoist will not lift –<br>Slight clicking                               | Improper assembly of ratchet disc, disc installed backwards, and making incorrect contact with the pawl.<br> | Reassemble the pawl and ratchet disc properly. Ensure that clicking sounds are heard before reuse.<br> |
| Hoist will not lift –<br>Not Clicking                                  | Pawl not engaging ratchet disc:<br>■ Dirt or corrosion between pawl and pawl shaft.  | Clean and lubricate pawl and pawl shaft.<br>   |
|  | Faulty pawl spring   | Replace pawl spring   |
|  | Loose selector pawl spring   | Perform hoist maintenance.  |
| Hoist will lift<br>intermittently –<br>Slight or irregular<br>clicking | Poor pawl movement caused by faulty pawl spring. The spring is loose or damaged.   | Perform maintenance and/or repair.  |
|  | Mis-assembly of pawl spring  | Reassemble it properly and ensure to check click sound of the pawl before reuse.  |

**Table 7-1 Troubleshooting Guide**

| Symptom   | Cause  | Remedy   |
|---|--|--|
| <p>During operation, hoist idles or load drifts</p>           | <p>Poor load sheave and load chain contact caused by improper chain-reeving.</p> | <p>Reassemble properly and ensure proper lifting before reuse.</p>  |
| <p>Hoist will not lift all the way (multiple fall hoists)</p> | <p>Capsized hook</p>   | <p>Reset the capsized hook.</p>                                    |
| <p>Hoist does not lift load smoothly.</p>                     | <p>Improper assembly of gear OR bearing broken.</p>                              | <p>Disassemble and reassemble gear train and/or replace bearing.</p>   |

**Table 7-1 Troubleshooting Guide**

**⚠ CAUTION** Improper braking may cause improper load lowering. The hoist utilizes dry friction discs; do not apply oil to friction surfaces.



| Symptom  | Cause  | Remedy  |
|--|--|---|
| Load will not go down  | Over tightened brake<br>The hoist left under load for a long period<br>Shock loaded during operation | Pull down hard (possibly with 2 people) on the hand chain to loosen brake.            |
|  | Brake rusted tight   | Replace the rusty components and perform hoist maintenance.                           |
| Load drifts or slips when lowering                             | A foreign object between friction surfaces.  | Remove the object and clean the surfaces. Replace if the friction surface is scarred. |
|  | Brake slip caused by significant rust  | Replace the rusty component and perform hoist maintenance.                            |
|  | Mis-assembly of friction plates, i.e. friction plates missing or at one side as shown.               | Reassemble properly as shown and ensure hoist functions properly before reuse.        |
|  |  |   |
|  | Cracked friction plate caused by overload  | Replace the friction plate and use the hoist properly within rated capacity.          |
| Friction plate wear caused by very frequent and long term use. | Perform hoist maintenance.   |   |



## **8.0 Warranty**

Buyer must notify HHI in writing within sixty (60) days of discovery of any alleged defect, if within the applicable warranty period.

All products sold by HHI are warranted to be free from defects in material and workmanship from date of shipment by HHI for the following periods:

- 1 year – Electric and Air Powered Hoists (excluding (N)ER2 Hoists and EQ/SEQ Hoists), Powered Trolleys, Powered Tiger Track Jibs and Gantries, Crane Components, Below the Hook Devices, Spare / Replacement Parts**
- 2 years – Manual Hoists & Trolleys, Beam Clamps**
- 3 years – (N)ER2 Hoists, EQ/SEQ Hoists, (T)EM/(T)SEM hoists, and RY Hoists**
- 5 years – Manual Tiger Track Jibs and Gantries, Hoist Motor Brakes for EQ/SEQ, (T)EM/(T)SEM, and RY**
- 10 years – (N)ER2 Brake, TNER Hoist Motor Brake, Tiger Track Workstation Cranes and Monorails**

The product must be used in accordance with manufacturer's recommendations and must not have been subject to abuse, lack of maintenance, misuse, negligence, or unauthorized repairs or alterations.

Should any defect in material or workmanship occur during the above time period in any product, as determined by HHI's inspection of the product, HHI agrees, at its discretion, either to replace (not including installation) or repair the part or product free of charge. For customers in the U.S., delivery shall be made F.O.B. HHI's place of business. For international customers, delivery shall be made FCA HHI place of business, United States of America (Incoterms 2010).

No warranty claim will be honored without a valid proof of purchase. Customer must obtain a Return Goods Authorization as directed by HHI or its published repair center prior to shipping product for warranty evaluation. An explanation of the complaint must accompany the product. Product must be returned freight prepaid. Upon repair, the product will be covered for the remainder of the original warranty period. Replacement parts installed after the original warranty period will only be eligible for replacement (not including installation) for a period of one year from the installation date. If it is determined there is no defect, or that the defect resulted from causes not within the scope of HHI's warranty, the customer will be responsible for the costs of returning the product.


HHI DISCLAIMS ANY AND ALL OTHER WARRANTIES OF ANY KIND, EXPRESSED OR IMPLIED, AS TO THE PRODUCT'S MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. HHI WILL NOT BE LIABLE FOR DEATH, INJURIES TO PERSONS OR PROPERTY OR FOR INCIDENTAL, CONTINGENT, SPECIAL OR CONSEQUENTIAL DAMAGES, LOSS OR EXPENSE ARISING IN CONNECTION WITH THE USE OR MISUSE OF THE PRODUCTS, REGARDLESS OF WHETHER THE DAMAGE, LOSS OR EXPENSE RESULTS FROM ANY ACT OR FAILURE TO ACT BY HHI, WHETHER NEGLIGENT OR WILLFUL, OR FROM ANY OTHER CAUSE.

**This Page Intentionally Left Blank**

## 9.0 Parts List

When ordering Parts, please provide the Hoist code number, lot number and serial number located on the Hoist nameplate (see Figure 9-1 below).


Reminder: Per Sections 1.1 and 3.4.4 to aid in ordering parts and product support, record the hoist Code, Lot and Serial Number in the space provided on the cover of this manual.



The parts list is arranged into the following sections:

| <b>Section</b>                            | <b>Page</b> |
|---|-------------|
| 9.1 1 to 5 Ton Parts.....                 | 44          |
| 9.2 Additional 2 through 5 Ton Parts..... | 46          |
| 9.3 Trolley Parts.....                    | 47          |
| 9.4 Optional Hooks.....                   | 49          |
| 9.5 Optional Chain Containers.....        | 50          |

### 9.1 1 to 5 Ton Parts




## 9.1 1 to 5 Ton Parts

| Fig. No. | Name                      | Parts / Hoist  | 1Ton        | 2 Ton     | 3 Ton       | 5 Ton      |           |
|----------|---------------------------|----------------|-------------|-----------|-------------|------------|-----------|
| 1        | Suspender                 | 1              | 50604       | 50622     | 50679       | 50725      |           |
| 3        | Top Pin                   | 1              | CF163010    |           | CF163015    |            |           |
| 4        | Bottom Hook Complete Set  | 1              | M3021A010   |           |             |            |           |
| 6        | Latch Assembly            | 1              | CF071010    |           |             |            |           |
| 7        | Chain Pin                 | 1              | M3041010    |           |             |            |           |
| 8        | Slotted Nut               | 1              | M2049010    |           |             |            |           |
| 9        | Split Pin                 | 1              | 9009411     |           |             |            |           |
| 10       | Body A                    | 1              | CF101010    |           | CF101015    |            |           |
| 11       | Body B                    | 1              | CF102010    |           | CF102015    |            |           |
| 12       | Name Plate<br>- Blank     | without rivets | 1           | CF800010B | CF800020B   | CF800030B  | CF800050B |
|          |                           | with rivets    | 1           | CF4800010 | CF4800020   | CF4800030  | CF4800050 |
| 13       | Frame                     | 1              | CF105010    |           | CF105015    |            |           |
| 14       | Pinion                    | 1              | CF111010**  |           | CF111015**  | CF111050** |           |
|          |                           |                | CF4111010*  |           | CF4111015*  | CF4111050* |           |
| 15       | Ball Bearing A            | 1              | 9000103     |           |             |            |           |
| 16       | Ball Bearing B            | 1              | 9000201     | 9000202   | 9000300     |            |           |
| 17       | Ball Bearing C            | 1              | 9000105     | 9000106   |             |            |           |
| 17A      | Ball Bearing D            | 1              | 9000105     | 9000106   |             |            |           |
| 18       | Load Sheave               | 1              | CF116010    | CF116015  | CF116A050   |            |           |
| 19       | Load Gear                 | 1              | CF114010    | CF114015  | CF116A050   |            |           |
| 20       | Chain Guide               | 1              | CF178010    | CF178015  |             |            |           |
| 21       | Stripper                  | 1              | CF162010    | CF162015  |             |            |           |
| 22       | Socket Bolt for Body      | 2              | 9091284     | 9091285   |             |            |           |
| 22A      | Socket Bolt for Body      | 2              | 9091282     | 9091283   |             |            |           |
| 23       | U-Nut for Body            | 4              | 9098506     |           |             |            |           |
| 24       | Pawl Pin                  | 1              | CF156005    |           |             |            |           |
| 25       | U-Nut for Fig. 24         | 1              | 9098506     |           |             |            |           |
| 26       | Pawl Spring               | 1              | CF158005    |           |             |            |           |
| 27       | Pawl                      | 1              | CF155005    |           |             |            |           |
| 28       | Snap Ring for Fig. 24     | 1              | 9047108     |           |             |            |           |
| 29       | Friction Disc             | 1              | CF153010**  |           |             |            |           |
|          |                           |                | M3153020*   |           |             |            |           |
| 30       | Ratchet Disc              | 1              | CF152010**  |           |             |            |           |
|          |                           |                | CF4152010*  |           |             |            |           |
| 31       | Bushing for Ratchet Disc  | 1              | M3154020*   |           |             |            |           |
| 32       | Friction Plate            | 2              | M3151020*   |           |             |            |           |
|          |                           | 1              | CF151010**  |           |             |            |           |
| 32-A     | Friction Plate            | 1              | CF150010**  |           |             |            |           |
| 33       | Hand Wheel                | 1              | CF115010**  |           | CF115015**  |            |           |
|          |                           |                | CF41115010* |           | CF41115015* |            |           |
| 34       | Wheel Stopper             | 1              | CF159010    |           |             |            |           |
| 35       | Wheel Stopper Pin         | 1              | M2167005    |           |             |            |           |
| 36       | Split Pin for Fig. 35     | 1              | 9009485     |           |             |            |           |
| 37       | Wheel Cover               | 1              | CF171010    | CF171015  |             |            |           |
| 38       | Screw for Fig. 37         | 3              | CF187005    |           |             |            |           |
| 39       | Spring Washer for Fig. 37 | 3              | 9012709     |           |             |            |           |
| 40       | Tail Pin                  | 1              | CF164010    | CF164015  |             |            |           |
| 41       | Socket Bolt for Fig. 40   | 1              | CF181010    |           |             |            |           |
| 42       | Load Chain                | ft.            | LCCF010     | LCCF015   |             |            |           |
| 43       | Hand Chain                | ft.            | HCCF005     |           |             |            |           |
| 77       | Warning Tag               | 1              | WTAG9       |           |             |            |           |
| 78       | Chain Stopper Link        | 1              | L4045030    |           |             |            |           |

\*CF4 model only

\*\*Parts discontinued


## 9.2 Additional 2 through 5 Ton Parts



**Figure 9-3 Additional 2 through 5 Ton Parts**

| Fig. No. | Name                     | Parts / Hoist | 2 Ton     | 3 Ton     | 5 Ton     |
|----------|--------------------------|---------------|-----------|-----------|-----------|
| 44       | Suspender                | 1             | 50622     | 50679     |           |
| 46       | Chain Pin                | 1             | CF041020  | M3041030  |           |
| 47       | Slotted Nut for Fig. 46  | 1             | M2049010  |           |           |
| 48       | Split Pin for Fig. 46    | 1             | 9009411   |           |           |
| 49       | Bottom Hook Complete Set | 1             | CF021A020 | M3021A030 |           |
| 50       | Bottom Yoke              | 2             | CF031020  | M3031030  |           |
| 51       | Bolt                     | 2             | 9091274   | 9091296   |           |
| 52       | U-Nut                    | 2             | 9098506   | 9098508   |           |
| 53       | Shaft                    | 1             | CF053020  | CF053030  |           |
| 54       | Solid Pin                | 2             | CF083020  |           |           |
|          | Spring Pin               | 1             |           | CF083030  |           |
| 55       | Idle Sheave              | 1             | CF051020  | CF051030  |           |
| 56       | Bottom Hook Assembly     | 1             | CF021020  | M3021030  |           |
| 57       | Latch Assembly           | 1             | CF071020  | CF071030  |           |
| 58       | Suspender Assembly       | 1             |           |           | 50727     |
| 59       | Suspender                | 1             |           |           | 50725     |
| 60       | Idle Sheave Bracket L.H. | 1             |           |           | 5072601   |
| 61       | Idle Sheave              | 1             |           |           | CF051030  |
| 62       | Shaft                    | 1             |           |           | CF053050  |
| 63       | Spring Pin               | 1             |           |           | CF083020  |
| 64       | Bolt                     | 2             |           |           | 9093153   |
| 65       | Lock Nut                 | 2             |           |           | 9098511   |
| 66       | Idle Sheave Bracket R.H. | 1             |           |           | 5072602   |
| 68       | Bottom Hook Complete Set | 1             |           |           | CF021A050 |
| 69       | Bottom Yoke Assembly     | 1             |           |           | CF031050  |
| 70       | Idle Sheave              | 1             |           |           | CF051030  |
| 71       | Shaft                    | 1             |           |           | CF053030  |
| 72       | Spring Pin               | 1             |           |           | CF083030  |
| 73       | Socket Bolt              | 2             |           |           | 9091296   |
| 74       | U-Nut                    | 2             |           |           | 9098508   |
| 75       | Bottom Hook Assembly     | 1             |           |           | M3021050  |
| 76       | Latch Assembly           | 1             |           |           | CF071050  |

### 9.3 Trolley Parts



**Figure 9-3 Trolley Parts**

#### Push Trolley Parts

| Fig. No. | Name                   | Parts / Hoist | 1Ton                              | 2 Ton      | 3 Ton      | 5 Ton      |
|----------|------------------------|---------------|-----------------------------------|------------|------------|------------|
| 78       | Side Plate A           | 1             | 50600                             | 50619      | 50685      | 50722      |
| 79       | Track Wheel S Assembly | 2             | T3P1102010                        | T3P1102020 | T3P1102030 | T3P1102050 |
| 80       | Washer                 | 4             | MS104010                          | MS104020   | MS104030   | MS104050   |
| 81       | Snap Ring              | 2             | 9047115                           | 9047120    | 9047125    | 9047135    |
| 83       | Snap Ring              | 2             | 9047115                           | 9047120    | 9047125    | 9047135    |
| 84       | Washer                 | 4             | MS104010                          | MS104020   | MS104030   | MS104050   |
| 85       | Track Wheel S Assembly | 2             | T3P1102010                        | T3P1102020 | T3P1102030 | T3P1102050 |
| 86       | Side Plate B           | 1             | 50601                             | 50620      | 50676      | 50723      |
| 87       | Nameplate              | 1             | NTH800010                         | NTH800020  | NTH800030  | NTH800050  |
| 88       | Adjusting Spacer       | 36            | 9005212                           | T3P116010  | 9005215    |            |
|          |                        | 34            |                                   |            |            | 50736      |
| 90       | Lock Nut               | 2             | 9098506                           | 9098508    |            |            |
| 91       | Split Pin              | 2             | 9009417-5                         | 9009413    |            | 9009433    |
| 92       | Bolt                   | 2             | 9093102                           | 9093126    | 9093127    | 9093129    |
| 93       | Suspension Shaft       | 2             | See Suspension Shaft Sizing Chart |            |            |            |
| 94       | Shaft Stopper Pin      | 2             | T3P156010                         | T6G156020  | MS164020   | MS164030   |

#### Geared Trolley Parts

| Fig. No. | Name                   | Parts / Hoist | 1Ton       | 2 Ton      | 3 Ton      | 5 Ton      |
|----------|------------------------|---------------|------------|------------|------------|------------|
| 96       | Slotted Nut            | 1             | T3G259010  |            |            |            |
| 97       | Washer                 | 1             | 9012515    |            |            |            |
| 98       | Hand Wheel             | 1             | T6G123010  |            |            |            |
| 99       | Side Plate G           | 1             | 50600G     | 50619G     | 50675      | 50721      |
| 100      | Pinion                 | 1             | T3G121020  |            |            |            |
| 101      | Track Wheel G Assembly | 2             | T3G1101010 | T3G1101020 | T3G1101030 | T3G1101050 |
| 102      | Washer                 | 4             | MS104010   | MS104020   | MS104030   | MS104050   |
| 103      | Snap Ring              | 4             | T3P106010  | T3P106020  | T3P106030  | T3P106050  |
| 104      | Hand Chain             | ft.           | HCCF005    |            |            |            |

### 9.3 Trolley Parts

#### Suspension Shaft Sizing Chart


| Fig. No. | Parts / Hoist | 1Ton                  |         | 2 Ton                 |         | 3 Ton                 |         | 5 Ton                 |         |
|----------|---------------|-----------------------|---------|-----------------------|---------|-----------------------|---------|-----------------------|---------|
|          |               | Flange Range (inches) | Part #  | Flange Range (inches) | Part #  | Flange Range (inches) | Part #  | Flange Range (inches) | Part #  |
| 93       | 2             | 2.32 to 5.16          | 5060501 | 3.72 to 5.97          | 5062401 | 3.62 to 6.26          | 5068001 | 5.12 to 7.11          | 5072901 |
|          |               | 5.17 to 7.16          | 5060502 | 5.98 to 7.97          | 5062402 | 6.27 to 8.26          | 5068002 | 7.12 to 9.11          | 5072902 |
|          |               | 7.17 to 9.16          | 5060503 | 7.98 to 9.97          | 5062403 | 8.27 to 10.26         | 5068003 | 9.12 to 11.11         | 5072903 |
|          |               | 9.17 to 11.16         | 5060504 | 9.98 to 11.97         | 5062404 | 10.27 to 12.26        | 5068004 | 11.12 to 13.11        | 5072904 |
|          |               | 11.17 to 13.16        | 5060505 | 11.98 to 13.97        | 5062405 | 12.27 to 14.26        | 5068005 | 13.12 to 15.11        | 5072905 |
|          |               | 13.17 to 15.16        | 5060506 | 13.98 to 15.97        | 5062406 | 14.27 to 16.26        | 5068006 | 15.12 to 17.11        | 5072906 |

### **⚠️WARNING**

Flange range shall not be changed in the field by purchasing the parts listed on this page; these parts are only for one-for-one replacement of the same part. Additional factory modifications to the trolley are required to increase or decrease the flange range of an existing trolley. Failure to comply may result in failure of the hoist suspension, dropped load, and severe injury or death.  
Please contact customer service for more information.



## 9.4 Optional Hooks



### Bullard® Hooks

| Fig. No. | Name                              | Parts Per Hoist | 1 Ton      | 2 Ton   | 3 Ton   | 5 Ton   |
|----------|-----------------------------------|-----------------|------------|---------|---------|---------|
| 7        | Bullard® Bottom Hook Complete Set | 1               | 6027802    | 6027805 | 6027807 | 6027808 |
| 8        | Bullard® Hook Assembly            | 1               | 60162      | 60165   | 60168   | 60169   |
| 9        | Bottom Yoke Kit                   | 1               | BYKITCB010 |         |         |         |
| 10       | Button Head Screw                 | 4               | 9012601    |         |         |         |
| 11       | Flexloc® Nut**                    | 4               | 9012603    |         |         |         |
| 12       | Warning Tag*                      | 1               | WTAG6*     |         |         |         |

\*Hoist with Bullard® Hook(s) must have WTAG6 and WTAG9 installed. (See page 6 for WTAG9).

\*\* See Table 6-3 in Owner's Manual for yoke nut torque specifications

### SmartLok™ Hooks\*

| Fig. No. | Name                               | Parts Per Hoist | 1 Ton    | 2 Ton     | 3 Ton    | 5 Ton |
|----------|------------------------------------|-----------------|----------|-----------|----------|-------|
| 7        | SmartLok™ Bottom Hook Complete Set | 1               | 60322    | 60325     | 60327    | 60355 |
| 10       | Button Head Screw                  | 2               |          | 9091274   | 9091296  |       |
| 11       | Flexloc® Nut***                    | 2               |          | ES857005S | ES066075 |       |
| 12       | Warning Tag                        | 1               | WTAG13** |           |          |       |

\* SmartLok™ Hook replaced Shur-loc® Hook offering in 2022.

\*\*Hoist with SmartLok™ Hook(s) must have WTAG9 and WTAG13 installed.

(See page 6 for WTAG9 and SmartLok Hook Supplement for WTAG13).

\*\*\*See Table 6-3 in Owner's Manual for yoke nut torque specifications

### Inspection Hooks

| Fig. No. | Name                     | Parts Per Hoist | 1 Ton       | 2 Ton | 3 Ton | 5 Ton |
|----------|--------------------------|-----------------|-------------|-------|-------|-------|
| 6        | Bottom Hook Complete Set | 1               | M3021A010IK |       |       |       |
| 7        | Hook W/Latch & Yoke      | 1               | M3021A010IH |       |       |       |
| 8        | Button Head Screw        | 2               | 9012601     |       |       |       |
| 9        | Flexloc® Nut**           | 2               | 9012603     |       |       |       |

\*\* See Table 6-3 in Owner's Manual for yoke nut torque specifications

## 9.5 Optional Chain Containers




Figure 9-5 CF4 Optional Chain Container

### NTH OPTIONAL "05" & "10" CHAIN CONTAINERS

| Fig. No. | Name                                 | Parts Per Hoist | 1 Ton   | 2 Ton   | 3 Ton   | 5 Ton |
|----------|--------------------------------------|-----------------|---------|---------|---------|-------|
|          | "05" Chain Container (BKC1) Assembly | 1               | 60713   | 60713   | 60715   |       |
| 1        | Chain Container                      | 1               | 50810   | 50810   | 50810   |       |
| 2        | Modified Stripper Ass'y              | 1               | 5076004 | 5076004 | 5080404 |       |
| 3        | Split Pin                            | 1               | 9009412 | 9009412 | 9009412 |       |
| 4        | Washer, 1/4                          | 1               | 9005205 | 9005205 | 9005205 |       |
| 5        | Link                                 | 1               | 5076005 | 5076005 | 5076005 |       |
| 6        | Washer, M8                           | 2               | 9012513 | 9012513 | 9012513 |       |
| 7        | Hex Head Bolt                        | 1               | 9093328 | 9093328 | 9093328 |       |
| 8        | Lock-Nut                             | 1               | 9098506 | 9098506 | 9098506 |       |
|          | "10" Chain Container (BKD1) Assembly | 1               | 60714   | 60714   | 60716   |       |
| 1        | Chain Container                      | 1               | 5080403 | 5080403 | 5080403 |       |
| 2        | Modified Stripper Ass'y              | 1               | 5076004 | 5076004 | 5080404 |       |
| 3        | Split Pin                            | 1               | 9009412 | 9009412 | 9009412 |       |
| 4        | Washer, 1/4                          | 1               | 9005205 | 9005205 | 9005205 |       |
| 5        | Link                                 | 1               | 5076005 | 5076005 | 5076005 |       |
| 6        | Washer, M8                           | 2               | 9012513 | 9012513 | 9012513 |       |
| 7        | Hex Head Bolt                        | 1               | 9093328 | 9093328 | 9093328 |       |
| 8        | Lock-Nut                             | 1               | 9098506 | 9098506 | 9098506 |       |

## 9.5 Optional Chain Containers




Figure 9-6 CF4 Optional Chain Container

### NTH OPTIONAL "15" CHAIN CONTAINERS

| Fig. No. | Name                                 | Parts Per Hoist | 1 Ton   | 2 Ton   | 3 Ton   | 5 Ton   |
|----------|--------------------------------------|-----------------|---------|---------|---------|---------|
|          | "15" Chain Container (BKC1) Assembly | 1               | 60717   | 60718   | 60719   | 60720   |
| 1        | Modified Stripper Ass'y              | 1               | 5087605 | 5087605 | *       | 6007702 |
| 2        | Suspension Bracket                   | 1               | 5087606 | 5087608 | *       | 6007704 |
| 3        | Flat Washer                          | 1               | 9012514 | 9012514 | 9012514 | 9012514 |
| 4        | Lock Nut                             | 1               | 9098508 | 9098508 | 9098508 | 9098508 |
| 5        | Bolt                                 | 2               | 9093327 | 9093327 | 9093327 | 9093327 |
| 6        | Lock Nut                             | 2               | 9098506 | 9098506 | 9098506 | 9098506 |
| 7        | Lock Washer                          | 2               | 9012711 | 9012711 | 9012711 | 9012711 |
| 8        | Chain Container                      | 1               | 5087601 | 5087601 | 5087601 | 5087601 |

\*Available on request

## NOTES

## NOTES

## **NOTES**

## NOTES

**HARRINGTON**<sup>®</sup>  
**HOISTS AND CRANES**

Harrington Hoists, Inc.  
401 West End Avenue  
Manheim, PA 17545

[www.harringtonhoists.com](http://www.harringtonhoists.com)

Toll Free: 800-233-3010  
Phone: 717-665-2000  
Fax: 717-665-2861

© HARRINGTON HOISTS, INC.  
ALL RIGHTS RESERVED

**NTHOM-ENG**