
TCR PARTS LIST

Large Capacity TCR Parts List


10 Ton & 25 Ton Capacity

Code, Lot and Serial Number

WARNING

This equipment should not be installed, operated or maintained by any person who has not read and understood all the contents of this manual. Failure to read and comply with the contents of this manual can result in serious bodily injury or death, and/or property damage.

HARRINGTON
HOISTS AND CRANES



C=CORD TYPE ONLY
P=PENDANT TYPE ONLY

TCR1000

TCR1000C2/P2

Figure Number	Name	Part Number	Parts Per Hoist
1A	METAL BUSHING	TCR426305J90	1
1B	DU BUSHING	TCR130212012	1
1C	O-RING	TCR131101012	1
2	O-RING	TCR131103035	1
3	HEX.SOCKET HEAD CAP SCREW M5X12	9091226	4
4	VALVE BODY	TCR426301A50	1
5	O-RING	TCR131151015	1
6	VALVE BUSHING	TCR426301A60	1
7	THROTTLE VALVE	TCR426301A70	1
9	VALVE SHAFT LEVER	TCR426301J80	1
10	VALVE BODY PACKING	TCR136102097	1
11	HEX.SOCKET HEAD CAP SCREW M8X25	9091273	4
12	THROTTLE VALVE SPRING	TCR130802270	2
13	SPRING GUIDE	TCR426301G20	2
14	RETAINER CLIP	TCR130307011	2
15	SPRING THRUST PLATE	TCR426301R80	2
16	PISTON	TCR426301F80	2
17	O-RING	TCR131151028	2
18	VALVE CAP	TCR426301B30	2
19	O-RING	TCR131103033	2
20	O-RING	TCR131151006	2
21	HEX.SOCKET HEAD CAP SCREW M6X20	9091250	8
22	CAP COVER	TCR426301C80	2
23	O-RING	TCR131103026	2
24	THROTTLE VALVE SPRING (L)	TCR130802271	2
25	SPRING SEAT	TCR426301B50	2
26	SPRING SEAT SHAFT	TCR426301B60	2
27	WASHER	MCR136102095	2
28	HEX. NUT M6	9158703	2
29	HEX.SOCKET HEAD CAP SCREW M5X35	9091232	8
30	ELEMENT HOLDER	TCR426221G50	2
31	ELEMENT	MCR136302010	2
32	PACKING	TCR136102094	4
34	JOINT (ELBOW)	TCR135108102	1
34A	JOINT (STRAIGHT)	TCR135108103	2
35	HEX.SOCKET HEAD CAP SCREW M5X10	9091225	1
40	LIMIT VALVE SHAFT	TCR426305T70	1
41	FLAT WASHER M12	9012515	1

Figure Number	Name	Part Number	Parts Per Hoist
42	RETAINING RING	9047112	1
43	HEX NUT M8	9093424	1
44	LIMIT VALVE SHAFT WASHER	TCR426305V30	1
45	VALVE SHAFT THRUST PLATE	TCR426305G80	1
60	PENDANT VALVE CP	AH420215VBC	1
60A	THROTTLE VALVE	AH420215VB0	2
60B	PUSH ROD	AH420215VC0	2
60C	O-RING	AH131118012	2
60D	O-RING	AH131117013	2
60E	PENDANT VALVE BODY CP	AH420215VRB	1
60EA	PENDANT VALVE BODY	AH420215VR0	1
60EB	BUSHING	AH420214VF0	2
60F	O-RING	AH131103016	2
60G	SPRING PIN 4.5X32	9148160	2
60H	PENDANT VALVE LEVER	AH420210VH0	2
60J	VALVE SPRING	AH130802030	2
60K	PENDANT VALVE CAP	AH420214V10	2
60L	O-RING	TCR131103022	2
60M	RETAINING RING	AH130303004	2
62	JOINT	TCR135108103	3
63	HINGE SCREW M6X30	9044403	1
64	HEX. NUT M6	9093420	1
65	PENDANT HOSE CP	60850	1
65A	HOSE	TCR137225020	1
65B	TUBE BLACK	TCR137208020	FT
65C	TUBE RED	TCR137209020	FT
65D	TUBE WHITE	TCR137210020	FT
65E	STRAIN RELIEF	ES625003	FT
65F	S TYPE WIRE	TCR130802081	1
66	PENDANT HOSE CP	60851	1
66B	HOSE	9013141	3@FT
66C	TUBE FITTING	AH137291310	3
66D	STRAIGHT CONNECTOR	9013151	2
66E	ELBOW CONNECTOR	9013152	1
65E	STRAIN RELIEF	ES625003	FT
65F	S TYPE WIRE	TCR130802081	1
70	FRONT PLATE	TCR426301K70	1
71	BEARING 6007ZZ	9000507	2
72	ROTOR	TCR426301K40	1
73	RETAINING RING	9047120	1
74	RETAINING RING	9047135	1
75	BRAKE WHEEL KEY	TCR130408110	1

TCR1000C2/P2


Figure Number	Name	Part Number	Parts Per Hoist
76	VANE	TCR137102012	8
77	CYLINDER	TCR426301K50	1
78	REAR PLATE	TCR426301K20	1
79	CYLINDER KNOCK	TCR130402008	1
80	CASE	TCR426307K80	1
81	MOTOR COVER	TCR426307N30	1
82	O RING	TCR131103063	1
83	O RING	TCR131103064	1
84	BRAKE VALVE	TCR426301W30	2
85	O RING	TCR131103007	2
86	BRAKE VALVE SPRING	TCR130802272	2
87	BRAKE SHIFTER (M)	TCR426301W80	1
88	BEARING	TCR130116011	2
89	BRAKE DISC	TCR426301P30	1
90	SHIFTER SPRING	TCR130802273	1
91	SHIFTER SPRING SEAT	TCR426301W70	1
92	BRAKE SHIFTER	TCR426301W90	1
93	BRAKE PISTON	TCR426301Q70	1
94	O RING	TCR131101077	1
95	BRAKE SPRING (S)	TCR130802274	1
96	BRAKE SPRING (L)	TCR130802275	1
97	BRAKE SPRING SEAT	TCR426301B70	1
98	BRAKE CASE	TCR426307P20	1
99	HEX.SOCKET SET SCREW M10X35	TCR132310035	1
100	HEX.NUT M10	TCR426301Q90	1
101	HEX.SOCKET HEAD CAP SCREW M10X85	90912140	4
102	SILENCER	TCR137402046	1
103	EXHAUST COVER	TCR426301Q60	1
105	HEX.SOCKET HEAD CAP SCREW M6X14	9091248	4
106	EXHAUST COVER SHAFT	TCR426301U90	1
107	O RING	TCR131103004	2
108	O RING	TCR131101004	2
110	COUPLING	TCR426301L20	1
111	PINION	TCR426301L30	1
112	FIRST IDLE GEAR	TCR426301L80	3
113	NEEDLE BEARING	TCR130131220	3
114	FIRST FRAME	TCR426301M10	1
115	BEARING	9000110	1
116	FIRST IDLE GEAR SHAFT	TCR426301M20	3
117	FIRST INTERNAL GEAR	TCR426301L90	1

Figure Number	Name	Part Number	Parts Per Hoist
118	CONED DISK SPRING	TCR426301L50	1
119	SECOND IDLE GEAR	TCR426301M40	3
120	NEEDLE BEARING	TCR130132520	3
121	SECOND FRAME	TCR426301M70	1
122	SECOND IDLE GEAR SHAFT	TCR426301M50	3
123	SECOND INTERNAL GEAR	TCR426301M60	1
124	BEARING	TCR130116024	2
125	INTERNAL GEAR SPACER	TCR426301K60	1
126	THIRD IDLE GEAR	TCR426301N40	3
127	NEEDLE BEARING	TCR130132530	3
128	THIRD FRAME	TCR426301N70	1
129	BEARING	9000502	1
130	RETAINING RING	9047232	1
131	THIRD IDLE GEAR SHAFT	TCR426301N50	3
132	THIRD INTERNAL GEAR	TCR426301N60	1
133	GEAR CASE	TCR426301N80	1
134	SPRING PIN 8X20	91481117	6
135	BRAND NAME PLATE - H'TON	80103	1
136	RIVET NO.0X3.2	MCR133001110	8
137	GEAR COVER	TCR426301N20	1
138	BEARING	9000202	1
139	O RING	TCR131117166	1
140	HEX. SOCKET HEAD CAP SCREW M10X25	9091294	6
141	NAME PLATE 10 TON	80104	1
145	LOAD SHEAVE	TCR426301R20	1
146	CHAIN GUIDE	TCR426301R30	1
147	BEARING	9000915	1
148	O RING	TCR131103063	1
149	CHAIN GUIDE COVER	TCR426301U80	1
150	BEARING	9001015	1
151	KNOCK PIN	TCR426301L60	3
152	CHAIN SEPARATOR	TCR426303R40	1
153	CHAIN SEPARATOR PIN	TCR426301U40	1
154	MIDDLE PLATE (G)	TCR426303C60	1
155	MIDDLE PLATE (M)	TCR426303C70	1
156	HEX SOCKET HEAD CAP SCREW M16X170	90912145	5
157	SPRING WASHER M16	9012715	5
158	HEX. NUT M16	9093439	5
159	LIMIT LEVER U	TCR426303R60	1
160	LIMIT LEVER D	TCR426303AC0	1
164	CONTROL LEVER	TCR426303L70	1

TCR1000C2/P2

Figure Number	Name	Part Number	Parts Per Hoist
165	HOOK CP	TCR426303S2B	2
165B	HOOK SAFETY CLAW	TCR420890P10	1
165C	HOOK SPRING	TCR130802046	1
165D	SPRING PIN 3X24	TCR130603024	1
166	HOOK END PIECE	TCR426303AH0	1
167	HANGER PIN	TCR426303AG0	2
168	WASHER	TCR426303R50	2
169	U NUT M16	9098516	2
170	SPRING WASHER M16	9012715	2
171	HEX. SOCKET HEAD CAP SCREW M12X60	90912120	2
172	CHAIN SET PLATE	TCR426303X40	1
173	CHAIN SET PLATE SHAFT	TCR426301X50	2
174	SPLIT PIN 5X35	9009445	3
175	HEX. SOCKET HEAD CAP SCREW M10X130	90912141	1
176	U NUT M10	9098508	1
177	PLAIN WASHER M10	9012514	1
178	CHAIN SET SPINDLE	TCR426303X60	1
179	CHAIN END CONNECTOR	TCR426301X70	1
180	CHAIN END PIN	TCR426301X80	1
181	SPLIT PIN 4X32	9009436	1
182	LOAD CHAIN	LCTCR10000	FT
190	FREE CHAIN WHEEL	TCR426303U20	1
191	FREE WHEEL PIN	TCR426303AJ0	1
192	YOKE	TCR426303Y60	1
193	HOOK SLIDE RING	TCR426303X90	1
194	NEEDLE BEARING	TCR130134020	4
195	SEAL	TCR131212040	2
196	THRUST BEARING	TCR130121114	1
197	HEX. SOCKET HEAD CAP SCREW M16X75	90912144	2
198	SPRING WASHER M16	9012715	2
199	HEX. NUT M16	9093439	2
210	DOMED CAP NUT M10	9158705	1
220	S TYPE WIRE	TCR130802081	2
221R	RED CORD	9013102	FT
221W	WHITE CORD	9013101	FT
222	GRIP (W)	AH136602625	1
223	GRIP (R)	AH136602626	1
224	HANDLE	AH136602627	1

Figure Number	Name	Part Number	Parts Per Hoist
225	HEX. SOCKET HEAD CAP PLUG	TCR134901002	1
226	HEX. SOCKET HEAD CAP PLUG	TCR420875BJ0	2
300	CHAMBER CAP	TCR426307AL0	1
301	HEX. SOCKET HEAD CAP SCREW M6X14	9091248	4
302	O RING	TCR131103063	1
303	O RING	MCR131103051	1
304	O RING	TCR131103005	5
305	VALVE BOX	TCR426307AM0	1
306	LIMIT SPOOL	TCR426307AN0	1
307	LIMIT SPOOL BUSHING	TCR426307AP0	1
308	BOX COVER	TCR426307AQ0	1
309	LIMIT RETAINER	TCR426307AR0	1
310	ADJUST COVER	TCR426307AS0	1
311	SPRING SEAT	TCR426307Z50	1
312	SPRING 13X64X2	TCR130802276	1
313	LIMIT GASKET	TCR136102170	1
314	HEX. SOCKET HEAD CAP SCREW M5X40	9091233	4
315	HEX. SOCKET HEAD CAP SCREW M5X14	9091227	8
316	HEX. SOCKET SET SCREW M6X25	TCR132306025	1
317	HEX. NUT M6	9043904	1
318	O-RING	TCR131103022	6
319	PARALLEL PIN 4X10	TCR130406005	3
320	RETAINING RING	9047232	1



TCR25000

TCR25000C2/P2

Figure Number	Name	Part Number	Parts Per Hoist
1A	METAL BUSHING	TCR426305J90	1
1B	DU BUSHING	TCR130212012	1
1C	O RING	TCR131101012	1
2	O RING	TCR131103035	1
3	HEX.SOCKET HEAD CAP SCREW M5X12	9091226	4
4	VALVE BODY	TCR426301A50	1
5	O RING	TCR131151015	1
6	VALVE BUSHING	TCR426301A60	1
7	THROTTLE VALVE	TCR426301A70	1
9	VALVE SHAFT LEVER	TCR426301J80	1
10	VALVE BODY PACKING	TCR136102097	1
11	HEX.SOCKET HEAD CAP SCREW M8X25	9091273	4
12	THROTTLE VALVE SPRING (S)	TCR130802270	2
13	SPRING GUIDE (S)	TCR426301G20	2
14	RETAINER CLIP	TCR130307011	2
15	SPRING THRUST PLATE	TCR426301R80	2
16	PISTON	TCR426301F80	2
17	O RING	TCR131151028	2
18	VALVE CAP	TCR426301B30	2
19	O RING	TCR131103033	2
20	O RING	TCR131151006	2
21	HEX.SOCKET HEAD CAP SCREW M6X20	9091250	8
22	CAP COVER	TCR426301C80	2
23	O RING	TCR131103026	2
24	THROTTLE VALVE SPRING (L)	TCR130802271	2
25	SPRING SEAT	TCR426301B50	2
26	SPRING SEAT SHAFT	TCR426301B60	2
27	WASHER	MCR136102095	2
28	HEX. NUT M6	9158703	2
29	HEX.SOCKET HEAD CAP SCREW M5X35	9091232	8
30	ELEMENT HOLDER	TCR426221G50	2
31	ELEMENT	MCR136302010	2
32	PACKING	TCR136102094	4
33	JOINT (STRAIGHT)	TCR135108103	2
34	JOINT (ELBOW)	TCR135108102	1
35	HEX.SOCKET HEAD CAP SCREW M5X10	9091225	1
40	LIMIT VALVE SHAFT	TCR426305T70	1
41	FLAT WASHER M12	9012515	1
42	RETAINING RING	9047112	1
43	HEX. NUT M8	9093424	1
44	LIMIT VALVE SHAFT WASHER	TCR426305V30	1

Figure Number	Name	Part Number	Parts Per Hoist
45	VALVE SHAFT THRUST PLATE	TCR426305G80	1
60	PENDANT VALVE CP	AH420215VBC	1
60A	THROTTLE VALVE	AH420215VB0	2
60B	PUSH ROD	AH420215VC0	2
60C	O-RING	AH131118012	2
60D	O-RING	AH131117013	2
60E	PENDANT VALVE BODY CP	AH420215VRB	1
60EA	PENDANT VALVE BODY	AH420215VR0	1
60EB	BUSHING	AH420214VF0	2
60F	O-RING	AH131103016	2
060G	SPRING PIN 4.5X32	9148160	2
60H	PENDANT VALVE LEVER	AH420210VH0	2
60J	VALVE SPRING	AH130802030	2
60K	PENDANT VALVE CAP	AH420214V10	2
60L	O-RING	TCR131103022	2
60M	RETAINING RING	AH130303004	2
62	JOINT	TCR135108103	3
63	HINGE SCREW M6X30	9044403	1
64	HEX. NUT M6	9093420	1
65	PENDANT HOSE CP	60850	1
65A	HOSE	TCR137225020	FT
65B	TUBE BLACK 8X6X2M	TCR137208020	FT
65C	TUBE RED 8X6X2M	TCR137209020	FT
65D	TUBE WHITE 8X6X2M	TCR137210020	FT
65E	STRAIN RELIEF	ES625003	FT
65F	S TYPE WIRE	TCR130802081	1
66	PENDANT HOSE CP	60851	1
66B	HOSE	9013141	3@FT
66C	TUBE FITTING	AH137291310	3
66E	JOINT (ELBOW)	9013152	1
66D	JOINT (STRAIGHT)	9013151	2
65E	STRAIN RELIEF	ES625003	FT
65F	S TYPE WIRE	TCR130802081	1
70	FRONT PLATE	TCR426301K70	1
71	BEARING	9000507	2
72	ROTOR	TCR426301K40	1
73	RETAINING RING	9047120	1
74	RETAINING RING	9047135	1
75	BRAKE WHEEL KEY	TCR130408110	1
76	VANE	TCR137102012	8
77	CYLINDER	TCR426301K50	1
78	REAR PLATE	TCR426301K20	1
79	CYLINDER KNOCK	TCR130402008	1
80	CASE	TCR426307K80	1

TCR25000

Figure Number	Name	Part Number	Parts Per Hoist
81	MOTOR COVER	TCR426307N30	1
82	O RING	TCR131103063	2
83	O RING	TCR131103064	1
84	BRAKE VALVE	TCR426301W30	2
85	O RING	TCR131103007	2
86	BRAKE VALVE SPRING	TCR130802272	2
87	BRAKE SHIFTER (M)	TCR426301W80	1
88	BEARING	TCR130116011	2
89	BRAKE DISC	TCR426301P30	1
90	SHIFTER SPRING	TCR130802273	1
91	SHIFTER SPRING SEAT	TCR426301W70	1
92	BRAKE SHIFTER (S)	TCR426301W90	1
93	BRAKE PISTON	TCR426301Q70	1
94	O RING	TCR131101077	1
95	BRAKE SPRING (S)	TCR130802274	1
96	BRAKE SPRING (L)	TCR130802275	1
97	BRAKE SPRING SEAT	TCR426301B70	1
98	BRAKE CASE	TCR426307P20	1
99	HEX.SOCKET SET SCREW M10X35	TCR132310035	1
100	HEX.NUT M10	TCR426301Q90	1
101	HEX.SOCKET HEAD CAP SCREW M10X85	90912140	4
102	SILENCER	TCR137402046	1
103	EXHAUST COVER	TCR426301Q60	1
105	HEX.SOCKET HEAD CAP SCREW M6X14	9091248	4
106	EXHAUST COVER SHAFT	TCR426301U90	1
107	O RING	TCR131103004	2
108	O RING	TCR131101004	2
110	COUPLING	TCR426305L20	1
111	PINION	TCR426305L30	1
112	FIRST IDLE GEAR	TCR426305L80	3
113	NEEDLE BEARING	TCR130131220	3
114	FIRST FRAME	TCR426305M10	1
115	BEARING	TCR130116011	1
116	FIRST IDLE GEAR SHAFT	TCR426305M20	3
117	FIRST INTERNAL GEAR	TCR426305L90	1
118	CONED DISK SPRING	TCR426305L40	1
119	SECOND IDLE GEAR	TCR426301M40	3
120	NEEDLE BEARING	TCR130132520	3
121	SECOND FRAME	TCR426301M70	1
122	SECOND IDLE GEAR SHAFT	TCR426301M50	3
123	SECOND INTERNAL GEAR	TCR426301M60	1
124	BEARING	TCR130116024	2
125	INTERNAL GEAR SPACER	TCR426301K60	1

Figure Number	Name	Part Number	Parts Per Hoist
126	THIRD IDLE GEAR	TCR426301N40	3
127	NEEDLE BEARING	TCR130132530	3
128	THIRD FRAME	TCR426305N71	1
129	PINION SPACER	TCR426305AD0	1
131	THIRD IDLE GEAR SHAFT	TCR426301N50	3
132	THIRD INTERNAL GEAR	TCR426301N60	1
133	THIRD INTERNAL GEAR SPACER	TCR426305N91	1
134	LAST IDLE GEAR	TCR426305V41	3
135	NEEDLE BEARING	TCR130132130	6
137	LAST FRAME	TCR426305V62	1
138	BEARING	9000107	1
139	BEARING	9000502	1
140	PARALLEL PIN 4X10	TCR130406005	3
141	LAST IDLE GEAR SHAFT	TCR426305V71	3
142	LAST INTERNAL GEAR	TCR426305V81	1
143	BEARING	9001212	2
144	BEARING	9000924	1
145	KNOCK PIN	TCR426305L61	6
146	GEAR CASE	TCR426305N80	1
147	SPRING PIN 8X20	91481117	3
148	INTERNAL GEAR KEY	TCR130408111	1
149	BRAND NAME PLATE	80103	1
150	RIVET NO.0X3.2	MCR133001110	8
151	GEAR COVER	TCR426305N20	1
152	BEARING	9000202	1
153	HEX. SOCKET HEAD CAP SCREW M10X25	9091294	6
154	NAME PLATE 25TON	80105	1
155	HEX. SOCKET HEAD CAP SCREW M16X70	90912143	6
156	HEX. SOCKET HEAD CAP SCREW M16X35	90912142	5
160	LOAD SHEAVE	TCR426305R22	1
161	SIDE PLATE (M)	TCR426305D50	1
162	SIDE PLATE (G)	TCR426305D61	1
163	BEARING 6220DDU	90010xx	1
164	CHAIN SEPARATOR	TCR426305R40	1
165	SPRING PIN 12X45	91481168	2
166	HEX. SOCKET HEAD CAP SCREW M24X90	90912146	2
167	SPRING WASHER M24 NARROW	9012719	4
168	HEX. NUT M24	9093445	2
169	O-RING	TCR131103195	1
170	CHAIN SET SPINDLE	TCR426305X60	1
171	HEX. NUT M24	9043911	1
172	SPRING WASHER M24	9012719	1

TCR25000

Figure Number	Name	Part Number	Parts Per Hoist
173	WASHER M20	9012519	1
174	LIMIT LEVER THRUST PLATE	TCR426305W60	1
175	LIMIT LEVER	TCR426305R61	1
176	DU BUSHING	TCR130220025	1
177	HEX. SOCKET HEAD CAP SCREW M10X15	9091292	1
178	CONTROL LEVER	TCR426305L70	1
179	LOAD CHAIN	LCTCR25000	FT
180	HOOK CP	TCR426305S2B	2
180B	HOOK SAFETY CLAW	TCR420745P10	1
180C	HOOK SPRING	TCR130802060	1
180D	HEX. SOCKET HEAD CAP SCREW M8X45	9091277	1
180E	U NUT M8	9098506	1
181	CHAIN END PIN	TCR426305X81	1
182	WASHER M24	9012521	3
183	WASHER M20	9012519	1
184	U NUT M-20	9098520	1
185	GEAR COVER PACKING	TCR136102100	1
186	INTERNAL GEAR PACKING (N)	TCR136102139	1
190	FREE CHAIN WHEEL	TCR426305U20	1
191	YOKE	TCR426305Y60	2
192	BEARING	TCR130125220	2
193	OIL SEAL	TCR131203150	2
194	THRUST BEARING	TCR130121220	1
195	HOOK THRUST RING	TCR426305X90	1
196	HEX. SOCKET HEAD CAP SCREW M24X90	90912146	2
197	SPRING WASHER M24 NARROW	9012719	4
198	HEX. NUT M24	9093445	2
201	LIMIT ROLLER	TCR426305F20	1
202	LIMIT SPACER	TCR426305F30	1
203	HEX. BOLT M12X50	9093374	1
204	PLAIN WASHER M12	9012515	1
205	HEX. NUT M12	9093433	1
206	SPRING WASHER M12	9012713	1
208	LIMIT LEVER (D)	TCR426305AC0	1
210	DOMED CAP NUT M10	9158705	1
220	S TYPE WIRE	TCR130802081	2
221R	THROTTLE VALVE CHANGE CORD - RED	9013102	6
221W	THROTTLE VALVE CHANGE CORD - WHITE	9013101	6
222	GRIP (W)	AH136602625	1
223	GRIP (R)	AH136602626	1
224	HANDLE	AH136602627	1
225	HEX. SOCKET HEAD CAP PLUG	TCR134901002	1

Figure Number	Name	Part Number	Parts Per Hoist
226	HEX. SOCKET HEAD CAP PLUG	TCR420875BJ0	2
300	CHAMBER CAP	TCR426307AL0	1
301	HEX.SOCKET HEAD CAP SCREW M6X14	9091248	4
302	O RING	TCR131103063	1
303	O RING	MCR131103051	1
304	O RING	TCR131103005	5
305	VALVE BOX	TCR426307AM0	1
306	LIMIT SPOOL	TCR426307AN0	1
307	LIMIT SPOOL BUSHING	TCR426307AP0	1
308	BOX COVER	TCR426307AQ0	1
309	LIMIT RETAINER	TCR426307AR0	1
310	ADJUST COVER	TCR426307AS0	1
311	SPRING SEAT	TCR426307Z50	1
312	SPRING 13X64X2	TCR130802276	1
313	LIMIT GASKET	TCR136102170	1
314	HEX. SOCKET HEAD CAP SCREW M5X40	9091233	4
315	HEX. SOCKET HEAD CAP SCREW M5X14	9091227	8
316	HEX. SOCKET SET SCREW M6X25	TCR132306025	1
317	HEX. NUT M6	9043904	1
318	O-RING	TCR131103022	6
319	PARALLEL PIN 4X10	TCR130406005	3
320	RETAINING RING	9047232	1

HARRINGTON HOISTS AND CRANES

www.harringtonhoists.com

Harrington Hoists, Inc.
401 West End Avenue
Manheim, PA 17545-1703
Phone: 717-665-2000
Toll Free: 800-233-3010
Fax: 717-665-2861

Harrington Hoists – Western Division
2341 Pomona Rincon Rd. #103
Corona, CA 92880-6973
Phone: 951-279-7100
Toll Free: 800-317-7111
Fax: 951-279-7500

TCRPL1025