



## SNER Electric Hoist Recommended Spare Parts 1/4 to 3 Ton

This information describes the recommended spare parts for the ¼ to 3 Ton SNER Electric Hoist.

Refer to the Owner's Manual for SNER Electric Chain Hoist complete parts list.

Part Name	Parts Per Hoist		Hoist Capacity Code						
			003S	005L	005S	010L	010S	020L	030C
Brake Drum Assembly		1	ER1BS5212		EP1CS5212		ER1DS5212		
Brake Spring		1	ER1BB9214		EP1CB9214		EP1DB9214		
Nut		1	ES217005S				ES217010S		
Lock Washer		1	ES218005S				ES218010S		
Bottom Hook Complete Set		1	ER1BS1011	ER1CS1011	ER1CS1011	ER1DS1011		ER1ES1011	ER1DR1011
Cushion Rubber	U	(x)	ER1BS9053 (2)	ER1CS9053 (2)		ER1DS9053 (2)		ER1ES9053 (1)	
Chain Spring	U	(x)					ES047015 (1)	ER1DL9051 (2)	
	U/L	(x)	ES047D003 (2)	ES047A005 (2)		ER1DS9051 (2)		ES047015 (2)	ER1DL9051 (3)
Start Switch Assembly		1	EP1CS2472						
Capacitor Assembly w/ Resistor		1	EP1BS1473		EP1CS1473		EP1BS1473		
Capacitor Assembly		1					ECP9911CP		
Electromagnetic Contactor		1	MGC22306D		MGC23306B				
Push Button Cord Assembly		1	EP1BS1557						EP1DR1557
Fuse - Trans. Secondary = 110V		1	9006271						

In the column "Parts Per Hoist" a designator is used for parts that apply only to a particular model or option. The designators are:

U = Upper Limit Switch only (standard)

U/L = Upper/Lower Limit Switch (optional)